

TA-AV590

SERVICE MANUAL

AEP Mode
UK Mode
E Mode
Chinese Mode




Photo : GRAY

SPECIFICATIONS

Amplifier section

| Items | Condition | Data |
|-----------------------------|-------------------------|--|
| Continuous RMS power output | 4 ohms, DIN 1 kHz | Front: 70 W + 70 W Center: 70 W Rear: 30 W + 30 W |
| | 4 ohms, 20 Hz-20 kHz | Front: 55 W + 55 W |
| Total harmonic distortion | 8 ohms, at 10 W output | Front: 0.03 % |

Input

| Audio | Input jack | Sensitivity | Impedance |
|-------|--|--|------------|
| | PHONO | 2 mV | 50 kilohms |
| | TUNER, AUX, TAPE VIDEO 1, 2, 3, 4, LD | 150 mV | |
| Video | CD | 200 mV | 15 kilohms |
| | VIDEO 1, 2, 3, 4, LD (phono jack) | 1 Vp-p | 75 ohms |
| | S VIDEO VIDEO 1, 4, LD | Luminance (Y) 1 Vp-p Chrominance (C) 0.286 Vp-p | 75 ohms |

Output

| Audio | Output jack | Sensitivity | Impedance |
|-------|--|--|---|
| | TAPE, VIDEO 1, 2 | 150 mV | 470 ohms |
| | PHONES | 3 mW (8 ohms) | Applied to low and high impedance headphones |
| Video | FRONT/CENTER/ MONO OUT | 1.5 V | 2 kilohms |
| | VIDEO 1, 2, MONITOR (phono jack) | 1 Vp-p | 75 ohms |
| | S VIDEO VIDEO 1, MONITOR | Luminance (Y) 1 Vp-p Chrominance (C) 0.286 Vp-p | 75 ohms |

Tone control

BASS: 100 Hz, ± 10 dB
TREBLE: 10 kHz, ± 10 dB
Center/rear output level:
+10 dB - -15 dB
Delay time: 20 ms fixed
Input balance: Auto

Surround

— Continued on page 2



INTEGRATED AV AMPLIFIER
SONY

General

| | |
|---------------------------------|--|
| Power requirements | AEP, German, Chinese, Singapore model : 220-230V AC, 50/60Hz UK model : 230V AC, 50/60Hz E model : 120, 220 or 240 V AC adjustable, 50/60Hz |
| Power consumption | 280 W |
| AC outlet (except for UK model) | One Switched, less than 100 W |
| Dimensions | Approx. 430 x 135 x 360 mm (w/h/d) (17 x 5 3/8 x 14 1/4 inches) |
| Mass | Approx. 10 kg (22 lb 1 oz) |
| Supplied accessories | Remote commander RM-P590 (1) Sony batteries SUM-3 (NS) (2) |

Design and specifications are subject to change without notice.

SAFETY-RELATED COMPONENT WARNING!!




COMPONENTS IDENTIFIED BY MARK  OR DOTTED LINE WITH MARK  ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

TABLE OF CONTENTS

| Section | Title | Page |
|--------------------------------------|-------|------|
| Specifications | | 1 |
| 1. GENERAL | | 3 |
| 2. EXPLANATION OF IC TERMINALS | | 6 |
| 3. DIAGRAMS | | |
| 3-1. Circuit Boards Location | | 8 |
| 3-2. Printed Wiring Boards-1 | | 9 |
| 3-3. Schematic Diagram-1 | | 13 |
| 3-4. Schematic Diagram-2 | | 17 |
| 3-5. Printed Wiring Boards-2 | | 21 |
| 4. EXPLODED VIEWS | | |
| 4-1. Front Panel Section | | 27 |
| 4-2. Chassis Section | | 28 |
| 5. ELECTRICAL PARTS LIST | | 29 |

MODEL IDENTIFICATION (Specification Label)




UK model : AC 230V~50/60Hz
AEP, German, Chinese,
Singapore model : AC 220-230V~50/60Hz
E model : AC 120, 220, 240V~50/60Hz

SECTION 1 GENERAL

This section is extracted from instruction manual.

A



Identifying the Parts and Controls


Front Panel and Display A

- 1 SYSTEM POWER switch**
Press to turn on/off the unit.
- 2 STANDBY indicator**
When this indicator lights up, you can turn on this unit with the remote commander.
- 3 Display**
- 4 Remote sensor**
- 5 SURROUND MODE button** (Page 48)
Press to change the surround mode. Each time this button is pressed, the surround mode changes as follows:

SURROUND OFF + DOLBY SUR
 +
 SIMULATED + HALL + THEATER
- 6 CENTER MODE button** (Page 48)
In the DOLBY SUR or THEATER mode, select the CENTER MODE according to the speaker placement. Each time this button is pressed, the CENTER MODE changes as follows:

PHANTOM + NORMAL
 +
 3 CH LOGIC + WIDE
- 7 MASTER VOLUME control** (Page 34)
Adjusts the sound volume. To increase the volume, turn the control clockwise. To decrease the volume, turn the control counterclockwise.
Adjusts the level of the sound output from the FRONT SPEAKERS, REAR SPEAKERS and CENTER SPEAKER terminals and the FRONT/CENTER/MONO OUT and PHONES jacks at the same time.
- 8 SPEAKERS switch** (Page 36)
Turn ON and OFF the sounds output from the FRONT SPEAKERS, REAR SPEAKERS and CENTER SPEAKER terminals and the FRONT/CENTER/MONO OUT jacks.
- 9 PHONES Jack**
Accepts the stereo phone plug of headphones. The jack outputs the sound of front speakers only. To listen to the program source only with the headphones, set the SPEAKERS switch to OFF.
- 10 VIDEO SELECTOR button**
Selects the video program source.
- 11 AUDIO SELECTOR button**
Selects the audio program source.
- 12 MIX button** (Page 38)
Press to combine a visual source and an audio source. Each time this button is pressed, the display changes as follows:
VISUAL → AUDIO → off
- 13 STEREO/MONO switch** (Page 16)
When using the monaural equipment, connect to either L or R jack of the amplifier and set STEREO/MONO switch to MONO. Same monaural signals are input on both L and R jacks and the monaural signal is also output from the FRONT OUT jacks.
- 14 BASS/TREBLE controls** (Page 34)
Adjust the BASS and TREBLE sound. Normally, set to the center position.
- 15 BALANCE control** (Page 34)
Adjusts balance of the front speaker sound. Normally set to the center position.
- 16 VIDEO 4 INPUT jacks** (Page 16)
Use when connecting the video camera, etc.


B



Identifying the Parts and Controls

Remote Commander B

- 1 LEARN button and indicator**
Stores functions of other remote commanders emitting infrared rays.
- 2 SYSTEM CONTROL/FUNCTION buttons** (Page 52, 58)
TAPE/AUX/CD/TUNER/PHONO/VIDEO 1/VIDEO 2/VIDEO 3/VIDEO 4/LD: Selects the each program source.
- 3 MIX button** (page 38)
Combines a visual source and audio source.
- 4 BACKGROUND button** (Page 56)
Operate other components temporarily while listening to or watching a programme.
- 5 SYSTEM OFF button** (page 54)
Turns off this unit and the components connected to the SWITCHED AC OUTLET.
When the unit is turned off by pressing this button, the STANDBY indicator lights up to show that the unit is in the STANDBY mode.
- 6 Surround buttons**
SURROUND ON/OFF: Turns on/off the surround mode.
DOLBY SURROUND, THEATER, HALL, SIMULATED: Select the each surround mode.
EFFECT: Adjust the overall presence of the sound field.
TEST TONE: Generates a test tone signal that is sent in succession to each speaker.
CENTER LEVEL +/-: Adjust the volume of center speaker.
REAR LEVEL +/-: Adjust the volume of rear speakers.
- 7 MASTER VOL +/- buttons**
Adjust the level of the sound output from the FRONT SPEAKERS, REAR SPEAKERS and CENTER SPEAKER terminals and the FRONT/CENTER/MONO OUT and PHONES jacks at the same time.
- 8 MUTING button**
Mutes the sound.



Identifying the Parts and Controls

9 Operation buttons

The each function of the operation button changes according as what component is being selected with the SYSTEM CONTROL/FUNCTION buttons.

| Button | Operates | Function |
|----------------------|---|---|
| 0-9 | Tuner | Selects preset numbers. |
| | CD player/ MD deck/ LD player | Selects track numbers. 0 selects track 10. |
| | TV/VCR | Selects channel numbers. |
| >10 | CD player/ Tape deck/ LD player/ MD deck | Selects track numbers over 10. |
| CH/ PRESET +/- | Tuner | Scans and selects preset stations. |
| | TV/VCR | Selects preset channels. |
| D. SKIP | CD player | Skips discs (CD player with multi-disc changer only.) |
| ◀▶ | CD player | Searches tracks (forward or backward). |
| | Tape deck/ MD deck/ VCR/LD player | Fastforwards or rewinds or searches. |
| ⏮▶⏭ | CD player/ MD deck/ LD player | Skips tracks. |
| | VCR | Searches index. |
| ⏸ | CD player/ Tape deck/ MD deck/ LD player/ VCR | Pauses play or record. (Also starts recording with components in record standby.) |
| ▶ | CD player/ Tape deck/ MD deck/ LD player/ VCR | Starts play. |
| ■ | CD player/ Tape deck/ MD deck/ LD player/ VCR | Stops play. |
| ◀ | Tape deck | Starts play on the reverse side. |
| ● | Tape deck/ MD deck | Sets tape decks to the record standby mode. |
| ● + ▶ | Tape deck/ VCR | Starts recording when pressed with (▶ or ◀ on tape deck). |

| Button | Operates | Function |
|---------------------|----------------------|---|
| RMS DIRECTION | Tape deck | Selects tape direction (for tape decks with the RMS* function.) |
| RMS CLEAR | Tape deck | Clears RMS* program (for tape decks with the RMS function.) |
| RMS/ START | Tape deck | Programs tracks (tape deck with the RMS* function only). |
| ENTER | TV/VCR | Changes channels when used with 0-9. |
| TV/ VIDEO | TV/VCR | Selects input signal: TV input or video input. |
| VISUAL POWER | TV/VCR/ LD player | Turns on or off the power. |
| TV CONTROL ON | TV | Turns on the TV, switches the input to "TV," and sets the remote to operate the TV. |
| -/- | TV | Selects the channel entry mode, either one or two digit. |
| SUB CH +/- | TV | Selects preset channels for the small picture.** |
| POSI | TV | Changes the position of the small picture.** |
| SWAP | TV | Swaps the small and the large picture.** |
| P IN P | TV | Activates the picture-in-picture function.** |
| JUMP | TV | Jumps back and forth between the previous and current channels. |
| ANT TV/ VTR | VCR | Selects output signal from the antenna terminal: TV signal or VCR program. |

* RMS: Random Music Sensor

** Only for Sony TVs with the picture-in-picture function

SECTION 2

EXPLANATION OF IC TERMINALS


IC801 (μ PD75212AGF-589-3BE)

| Pin No. | Pin name | I/O | Description |
|---------|-----------------|-----|--|
| 1 | RESET | I | System set input terminal. |
| 2 | 11G | O | Fluorescent indicator tube drive. |
| 3 | 10G | O | Fluorescent indicator tube drive. |
| 4 | 9G | O | Fluorescent indicator tube drive. |
| 5 | 8G | O | Fluorescent indicator tube drive. |
| 6 | 7G | O | Fluorescent indicator tube drive. |
| 7 | 6G | O | Fluorescent indicator tube drive. |
| 8 | 5G | O | Fluorescent indicator tube drive. |
| 9 | 4G | O | Fluorescent indicator tube drive. |
| 10 | 3G | O | Fluorescent indicator tube drive. |
| 11 | 2G | O | Fluorescent indicator tube drive. |
| 12 | 1G | O | Fluorescent indicator tube drive. |
| 13 | NC | — | Not used. (OPEN) |
| 14 | NC | — | Not used. (OPEN) |
| 15 | NC | — | Not used. (OPEN) |
| 16 | P12 | O | Fluorescent indicator tube drive. |
| 17 | P11 | O | Fluorescent indicator tube drive. |
| 18 | — 30 | — | Fluorescent indicator tube drive — 30V power supply. |
| 19 | — 4 | — | Fluorescent indicator tube drive — 4V power supply. |
| 20 | P10 | O | Fluorescent indicator tube drive. |
| 21 | P9 | O | Fluorescent indicator tube drive. |
| 22 | P8 | O | Fluorescent indicator tube drive. |
| 23 | P7 | O | Fluorescent indicator tube drive. |
| 24 | P6 | O | Fluorescent indicator tube drive. |
| 25 | P5 | O | Fluorescent indicator tube drive. |
| 26 | V _{DD} | — | Power supply. (+5V) |
| 27 | P4 | O | Fluorescent indicator tube drive. |
| 28 | P3 | O | Fluorescent indicator tube drive. |
| 29 | P2 | O | Fluorescent indicator tube drive. |
| 30 | P1 | O | Fluorescent indicator tube drive. |
| 31 | STOP | I | Power break detection input terminal. |
| 32 | FCK | O | Data transfer clock output to audio-video function switch. |
| 33 | FDT | O | Serial data output to audio-video function switch. |
| 34 | P-SW | I | Power SW ON/OFF detection. |
| 35 | SIRCS | I | Remote control receive detection. |
| 36 | KEY | I | Key matrix input terminal. |
| 37 | PROTECT | I | Speaker output protection detection input. |
| 38 | SWP | I | Power SW input detection. |
| 39 | VA | O | Video function switch control terminal. |
| 40 | VB | O | Video function switch control terminal. |

| Pin No. | Pin name | I/O | Description |
|---------|----------|-----|--|
| 41 | VE | O | Video function switch control terminal. |
| 42 | INH | O | Video 1 picture output loop cut control terminal. |
| 43 | NC | — | Not used. (OPEN) |
| 44 | RYS | O | Surround speaker output ON/OFF control. |
| 45 | RYC | O | Center speaker output ON/OFF control. |
| 46 | RYF | O | Front speaker output ON/OFF control. |
| 47 | SCE | O | Data latch output to surround processor. |
| 48 | SCK | O | Digital transfer clock output to surround processor. |
| 49 | SDT | O | Serial data output to surround processor. |
| 50 | MON | O | STEREO/MONO control terminal. |
| 51 | NC | — | Not used. (OPEN) |
| 52 | NC | — | Not used. (OPEN) |
| 53 | FCE | O | Data latch output to audio-video function switch |
| 54 | NC | — | Not used. (OPEN) |
| 55 | NC | — | Not used. (OPEN) |
| 56 | X1 | I | Main system clock terminal. (4.19MHz) |
| 57 | X2 | I | Main system clock terminal. (4.19MHz) |
| 58 | Vss | — | Power supply terminal. (GND) |
| 59 | XT1 | I | Subsystem clock terminal. (Not used) |
| 60 | XT2 | I | Subsystem clock terminal. (Not used) |
| 61 | RY-P | O | Power ON/OFF relay drive terminal. |
| 62 | MUT | O | Mute control terminal. |
| 63 | VL — | O | Volume motor control terminal. (DOWN) |
| 64 | VL+ | O | Volume motor control terminal. (UP) |

SECTION 3 DIAGRAMS

3-1. CIRCUIT BOARDS LOCATION




3-2. PRINTED WIRING BOARDS-1

● SEMICONDUCTOR LOCATION

| Ref. No. | Location | Ref. No. | Location |
|----------|----------|----------|----------|
| D001 | H-3 | Q006 | G-2 |
| D002 | G-2 | Q007 | G-2 |
| D008 | G-4 | Q008 | H-5 |
| D501 | J-3 | Q009 | H-6 |
| D502 | I-2 | Q011 | G-5 |
| D508 | J-4 | Q013 | H-5 |
| D551 | F-3 | Q015 | H-3 |
| D552 | E-2 | Q501 | J-2 |
| D558 | E-4 | Q502 | I-2 |
| D701 | C-12 | Q503 | J-2 |
| D702 | C-12 | Q504 | I-2 |
| D703 | D-12 | Q505 | I-2 |
| D704 | D-12 | Q506 | I-2 |
| D710 | H-12 | Q507 | I-2 |
| D711 | G-12 | Q508 | J-5 |
| D712 | F-9 | Q509 | J-6 |
| D717 | H-10 | Q511 | I-5 |
| D720 | I-12 | Q513 | J-5 |
| D721 | G-12 | Q515 | J-3 |
| D722 | F-9 | Q551 | F-2 |
| D725 | I-12 | Q552 | E-2 |
| D726 | H-12 | Q553 | F-2 |
| D727 | D-10 | Q554 | E-2 |
| D901 | H-24 | Q555 | E-2 |
| D902 | I-24 | Q556 | E-2 |
| D903 | I-24 | Q557 | E-2 |
| D904 | I-25 | Q558 | E-5 |
| D905 | I-25 | Q559 | E-6 |
| D906 | I-25 | Q561 | E-6 |
| D907 | I-24 | Q536 | F-5 |
| D908 | I-23 | Q565 | F-4 |
| D909 | I-23 | Q701 | C-12 |
| D910 | I-22 | Q702 | C-12 |
| D920 | J-9 | Q703 | C-12 |
| D921 | K-10 | Q710 | G-12 |
| D922 | K-9 | Q715 | H-12 |
| D923 | B-10 | Q720 | G-12 |
| D924 | B-10 | Q725 | H-12 |
| D925 | C-9 | Q901 | H-24 |
| D927 | J-9 | Q902 | J-23 |
| D929 | K-9 | Q903 | I-22 |
| | | Q904 | I-23 |
| | | Q905 | I-22 |
| IC601 | D-6 | Q906 | I-21 |
| IC651 | C-6 | Q921 | K-9 |
| Q001 | H-2 | | |
| Q002 | G-2 | | |
| Q003 | H-2 | | |
| Q004 | G-2 | | |
| Q005 | G-2 | | |

Note:

- — : parts extracted from the component side.
- ⊙ : Pattern on the side which is seen.
- Abbreviation
G : German
SP : Singapore
CH : Chinese



15

16

17

18


19

20

21


22

23




MODEL


[VS BOARD]



[CNP BOARD]





● Refer to page 25 for IC Block Diagrams.






【PS BOARD】








24

25

26

27

28




istwa


ami

erym


● Refer to page 25 for IC Block Diagrams.





F
G
H
I
J
K
L
M
N
O
P
Q
R



【VIDEO BOARD】







【 PANEL BOARD 】

(B) TO PS BOARD
CNPS40
(Page 14)

BOARD]

S VIDEO

R284 68

VIDEO

L

AUDIO

R

VIDEO 4 INPUT

TO CNA BOARD
CNFBZ
(Page 14)

SWB SWB
SWA SWA
SWS SWS
RYS RYS
RYC RYC
RYF RYF
RYP RYP
PROTECT
STOP
F1
F2
-FL
S.6
BGND

CNFAB1
17P

FCK
FDT
SIRCS
VA
VB
VE
INH
SCE
SCK
SDT
FCE
MQNO
MUTE
S.6
B GND

IC802
SIRCS DETECTOR

IC802
SIRCS DETECTOR

1 2 3

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

5.2

FL801

1 2 3

4 5 6 7 8 9 10 11 12 13 14 15 16 17

18 19 20 21 22 23 24 25 26 27 28 29 30

31 32 33 34 35 36 37 38 39 40

41 42 43 44 45 46 47 48 49 50

51 52 53 54 55 56 57 58 59 60

61 62 63 64 65 66 67 68 69 70

71 72 73 74 75 76 77 78 79 80

81 82 83 84 85 86 87 88 89 90

91 92 93 94 95 96 97 98 99 100

101 102 103 104 105 106 107 108 109 110

111 112 113 114 115 116 117 118 119 120

121 122 123 124 125 126 127 128 129 130

131 132 133 134 135 136 137 138 139 140

141 142 143 144 145 146 147 148 149 150

151 152 153 154 155 156 157 158 159 160

161 162 163 164 165 166 167 168 169 170

171 172 173 174 175 176 177 178 179 180

181 182 183 184 185 186 187 188 189 190

191 192 193 194 195 196 197 198 199 200

201 202 203 204 205 206 207 208 209 210

211 212 213 214 215 216 217 218 219 220

221 222 223 224 225 226 227 228 229 230

231 232 233 234 235 236 237 238 239 240

241 242 243 244 245 246 247 248 249 250

251 252 253 254 255 256 257 258 259 260

261 262 263 264 265 266 267 268 269 270

271 272 273 274 275 276 277 278 279 280

281 282 283 284 285 286 287 288 289 290

291 292 293 294 295 296 297 298 299 300

301 302 303 304 305 306 307 308 309 310

311 312 313 314 315 316 317 318 319 320

321 322 323 324 325 326 327 328 329 330

331 332 333 334 335 336 337 338 339 340

341 342 343 344 345 346 347 348 349 350

351 352 353 354 355 356 357 358 359 360

361 362 363 364 365 366 367 368 369 370

371 372 373 374 375 376 377 378 379 380

381 382 383 384 385 386 387 388 389 390

391 392 393 394 395 396 397 398 399 400

401 402 403 404 405 406 407 408 409 410

411 412 413 414 415 416 417 418 419 420

421 422 423 424 425 426 427 428 429 430

431 432 433 434 435 436 437 438 439 440

441 442 443 444 445 446 447 448 449 450

451 452 453 454 455 456 457 458 459 460

461 462 463 464 465 466 467 468 469 470

471 472 473 474 475 476 477 478 479 480

481 482 483 484 485 486 487 488 489 490

491 492 493 494 495 496 497 498 499 500

501 502 503 504 505 506 507 508 509 510

511 512 513 514 515 516 517 518 519 520

521 522 523 524 525 526 527 528 529 530

531 532 533 534 535 536 537 538 539 540

541 542 543 544 545 546 547 548 549 550

551 552 553 554 555 556 557 558 559 560

561 562 563 564 565 566 567 568 569 570

571 572 573 574 575 576 577 578 579 580

581 582 583 584 585 586 587 588 589 590

591 592 593 594 595 596 597 598 599 600

601 602 603 604 605 606 607 608 609 610

611 612 613 614 615 616 617 618 619 620

621 622 623 624 625 626 627 628 629 630

631 632 633 634 635 636 637 638 639 640

641 642 643 644 645 646 647 648 649 650

651 652 653 654 655 656 657 658 659 660

661 662 663 664 665 666 667 668 669 670

671 672 673 674 675 676 677 678 679 680

681 682 683 684 685 686 687 688 689 690

691 692 693 694 695 696 697 698 699 700

701 702 703 704 705 706 707 708 709 710

711 712 713 714 715 716 717 718 719 720

721 722 723 724 725 726 727 728 729 730

731 732 733 734 735 736 737 738 739 740

741 742 743 744 745 746 747 748 749 750

751 752 753 754 755 756 757 758 759 760

761 762 763 764 765 766 767 768 769 770

771 772 773 774 775 776 777 778 779 780

781 782 783 784 785 786 787 788 789 790

791 792 793 794 795 796 797 798 799 800

801 802 803 804 805 806 807 808 809 810

811 812 813 814 815 816 817 818 819 820

821 822 823 824 825 826 827 828 829 830

831 832 833 834 835 836 837 838 839 840

841 842 843 844 845 846 847 848 849 850

851 852 853 854 855 856 857 858 859 860

861 862 863 864 865 866 867 868 869 870

871 872 873 874 875 876 877 878 879 880

881 882 883 884 885 886 887 888 889 890

891 892 893 894 895 896 897 898 899 900

901 902 903 904 905 906 907 908 909 910

911 912 913 914 915 916 917 918 919 920

921 922 923 924 925 926 927 928 929 930

931 932 933 934 935 936 937 938 939 940

941 942 943 944 945 946 947 948 949 950

951 952 953 954 955 956 957 958 959 960

961 962 963 964 965 966 967 968 969 970

971 972 973 974 975 976 977 978 979 980

981 982 983 984 985 986 987 988 989 990

991 992 993 994 995 996 997 998 999 1000

1001 1002 1003 1004 1005 1006 1007 1008 1009 1010

1011 1012 1013 1014 1015 1016 1017 1018 1019 1020

1021 1022 1023 1024 1025 1026 1027 1028 1029 1030


1031 1032 1033 1034 1035 1036 1037 1038 1039 1040


1041 1042 1043 1044 1045 1046 1047 1048 1049 1050

1051 1052 1053 1054 1055 1056 1057 1058 1059 1060


1061 1062 1063 1064 1065 1066 1067 1068 1069 1070

1071 1072 1073 1074 1075 1076 1077 1078 10







IC801
#PD75212AGF-
-589-58E





- **WAVEFORMS**



Note :

- All capacitors are in μF unless otherwise noted. pF : μF 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and $\frac{1}{4}\text{W}$ or less unless otherwise specified.
- % : indicates tolerance.
- Δ : internal component.
-  : fusible resistor.

Note : The components identified by mark  or dotted line with mark  are critical for safety.
Replace only with part number specified.

- **[B+]** : B+ Line
- **[B-]** : B - Line
- Voltage and waveforms are dc with respect to ground under no-signal conditions.
no mark : PHONO
- Voltages are taken with a VOM (Input impedance 10M Ω).
Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with a oscilloscope.
Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to waveforms.
- Signal path.



● SEMICONDUCTOR LOCATION


| Ref. No. | Location | Ref. No. | Location |
|----------|----------|----------|----------|
| D290 | A - 12 | IC801 | J - 11 |
| D301 | E - 2 | IC802 | K - 12 |
| D801 | K - 10 | IC921 | F - 5 |
| D802 | I - 14 | IC922 | E - 5 |
| D803 | I - 14 | IC923 | F - 6 |
| D804 | K - 14 | | |
| D805 | K - 14 | Q201 | B - 19 |
| D806 | I - 14 | Q202 | B - 19 |
| D807 | I - 14 | Q203 | B - 18 |
| D808 | J - 13 | Q204 | B - 17 |
| | | Q205 | B - 16 |
| D809 | J - 13 | | |
| D812 | J - 9 | Q206 | B - 16 |
| D813 | J - 13 | Q207 | B - 17 |
| D814 | K - 10 | Q251 | B - 15 |
| D815 | H - 5 | Q252 | B - 15 |
| | | Q253 | B - 13 |
| D911 | K - 13 | | |
| | | Q254 | B - 14 |
| | | Q255 | B - 13 |
| IC101 | C - 2 | Q256 | B - 12 |
| IC102 | C - 4 | Q290 | A - 12 |
| IC103 | E - 3 | Q291 | B - 12 |
| IC104 | C - 3 | | |
| IC105 | C - 5 | Q303 | F - 2 |
| | | Q304 | I - 5 |
| IC201 | C - 16 | Q305 | I - 5 |
| IC251 | C - 13 | Q306 | I - 5 |
| IC252 | C - 12 | Q307 | I - 5 |
| IC301 | G - 3 | | |
| IC302 | J - 3 | Q308 | I - 5 |
| IC303 | J - 6 | | |
| IC304 | J - 5 | | |
| IC306 | J - 24 | | |
| IC402 | I - 10 | | |
| IC654 | I - 23 | | |

Note:


- : parts extracted from the component side.
- : parts mounted on the conductor side.
- ▤ : Pattern on the side which is seen.

- IC BLOCK DIAGRAMS


IC102 M5218AL




IC104, 105 LC7822





IC201, 251, 252 SN761200




IC302 LV1011






IC301 LA2785



IC654 LB1639



SECTION 4 EXPLODED VIEWS

NOTE:

- -XX, -X mean standardized parts, so they may have some difference from the original one.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Color indication of Appearance Parts
Example :
KNOB, BALANCE (WHITE)....(RED)


↑ ↑
Parts color Cabinet's color

- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (# mark) list and accessories and packing materials are given in the last of this parts list.

The components identified by mark or dotted line with mark are critical for safety. Replace only with part number specified.

- Abbreviation
G : German
SP : Singapore
CH : Chinese


4-1. FRONT PANEL SECTION



| Ref.No. | Part No. | Description | Remark |
|---------|--------------|-----------------------------------|--------|
| 1 | 4-954-972-21 | PANEL, FRONT (BLACK) (AEP, UK, G) | |
| 1 | 4-954-972-31 | PANEL, FRONT (GRY) (E, SP, CH) | |
| * 2 | 1-657-056-11 | HP BOARD | |
| 3 | 4-924-920-13 | CASE (GRY) (E, SP, CH) | |
| 3 | 4-924-920-71 | CASE (BLACK) (AEP, UK, G) | |
| 4 | 3-704-366-01 | SCREW (CASE) (M3×8) | |
| 5 | 4-917-460-81 | KNOB, POWER (BLACK) (AEP, UK, G) | |
| 5 | 4-917-460-91 | KNOB, POWER (GRY) (E, SP, CH) | |
| * 6 | 1-657-058-11 | PW. SW BOARD | |
| * 7 | 1-657-055-11 | SP. SW BOARD | |
| 8 | 4-951-620-01 | SCREW (2.6X8), +BVTP | |
| 9 | 4-954-978-01 | BUTTON (10) (BLACK) (AEP, UK, G) | |
| 9 | 4-954-978-11 | BUTTON (10) (GRY) (E, SP, CH) | |
| 10 | X-4946-097-2 | BASE ASSY, PANEL (AEP, UK, G) | |
| 10 | X-4946-100-2 | BASE ASSY, PANEL (E, SP, CH) | |

| Ref.No. | Part No. | Description | Remark |
|---------|--------------|--------------------------------|--------|
| 11 | 4-954-979-01 | KNOB (18) (BLACK) (AEP, UK, G) | |
| 11 | 4-954-979-11 | KNOB (18) (GRY) (E, SP, CH) | |
| * 12 | A-4378-427-A | PANEL BOARD, COMPLETE | |
| 13 | 1-773-644-11 | WIRE (FLAT TYPE) (17 CORE) | |
| 14 | 1-773-623-11 | WIRE (FLAT TYPE) (15 CORE) | |
| * 15 | 1-657-059-11 | CNL BOARD | |
| * 16 | 1-657-052-11 | VOL BOARD | |
| * 17 | 1-657-054-11 | VF BOARD | |
| * 18 | 4-954-977-01 | HOLDER, FL | |
| * 19 | 4-955-901-01 | CUSHION (FL) | |
| 20 | X-4942-974-1 | KNOB (50) ASSY (AEP, UK, G) | |
| 20 | X-4942-976-1 | KNOB (50) ASSY (E, SP, CH) | |
| 21 | 4-942-568-01 | EMBLEM (NO. 5), SONY | |
| FL801 | 1-517-440-11 | INDICATOR TUBE, FLUORESCENT | |

4-2. CHASSIS SECTION



The components identified by mark or dotted line with mark are critical for safety. Replace only with part number specified.

| Ref. No. | Part No. | Description | Remark | Ref. No. | Part No. | Description | Remark |
|----------|--------------|---|--------|----------|--------------|--|--------|
| * 51 | 1-533-213-31 | HOLDER, FUSE | | * 68 | 1-657-069-11 | CND BOARD | |
| * 52 | 1-657-064-11 | CNT2 BOARD | | * 69 | 1-657-066-11 | CNB BOARD | |
| * 53 | 1-657-057-11 | VS BOARD (E) | | * 70 | 1-657-068-11 | SPF BOARD | |
| * 54 | 1-657-063-11 | CNT1 BOARD | | * 71 | 3-309-144-21 | HEAT SINK | |
| * 55 | 4-949-235-01 | HOOK (UK) | | * 72 | A-4378-447-A | MAIN BOARD, COMPLETE | |
| * 56 | A-4378-436-A | AC BOARD, COMPLETE (AEP, G, SP, CH) | | 73 | 4-956-885-11 | FOOT (F58175S2W) (BLACK) (AEP, UK, G) | |
| * 56 | A-4378-437-A | AC BOARD, COMPLETE (UK) | | 73 | 4-956-885-21 | FOOT (F58175S2W) (GRY) (E, SP, CH) | |
| * 56 | A-4378-438-A | AC BOARD, COMPLETE (E) | | 74 | 4-956-370-02 | BAND, PLUG FIXED (UK) | |
| 57 | 3-704-515-11 | SCREW (BV/RING) | | 75 | 1-569-007-11 | ADAPTER, CONVERSION 2P (E) | |
| * 58 | 1-657-062-11 | CNA BOARD | | CNJ901 | 1-540-043-21 | OUTLET, AC (AC OUTLET) (NONPOLAR) (3P) (E) | |
| * 59 | 1-657-365-11 | CNP BOARD | | CNJ902 | 1-526-794-11 | OUTLET, AC (AEP, G, SP, CH) | |
| * 60 | A-4378-449-A | PS BOARD, COMPLETE | | CNP1 | 1-558-943-41 | CORD, POWER (E) | |
| 61 | 3-905-609-01 | SCREW (TRANSISTOR) | | CNP1 | 1-575-651-21 | CORD, POWER (AEP, G, SP, CH) | |
| * 62 | A-4378-440-A | AMP BOARD, COMPLETE | | CNP1 | 1-696-586-11 | CORD, POWER (UK) | |
| * 63 | 3-703-244-00 | BUSHING (2104), CORD (AEP, UK, G, SP, CH) | | F1 | 1-532-286-00 | FUSE (T2.5AL/250V) | |
| * 63 | 3-703-571-11 | BUSHING (S) (4516), CORD (E) | | F2 | 1-532-286-00 | FUSE (T2.5AL/250V) (AEP, G, SP, CH) | |
| 64 | 4-947-010-01 | SCREW, FEEDER FIXED | | F3 | 1-532-286-00 | FUSE (T2.5AL/250V) (E) | |
| * 65 | 4-954-970-71 | PANEL, BACK (AEP, G, SP, CH) | | F901 | 1-532-299-00 | FUSE (T5AL/250V) | |
| * 65 | 4-954-970-81 | PANEL, BACK (UK) | | F902 | 1-532-299-00 | FUSE (T5AL/250V) | |
| * 65 | 4-954-970-91 | PANEL, BACK (E) | | T1 | 1-427-982-11 | TRANSFORMER, POWER (AEP, UK, G, SP, CH) | |
| * 66 | 1-657-067-11 | SPC BOARD | | T1 | 1-427-983-11 | TRANSFORMER, POWER (E) | |
| * 67 | A-4378-428-A | VIDEO BOARD, COMPLETE | | | | | |

SECTION 5 ELECTRICAL PARTS LIST

AC

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX, -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
All resistors are in ohms
METAL : Metal-film resistor
METAL OXIDE : Metal oxide-film resistor
F : nonflammable

- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
In each case, u : μ , for example :
uA.... : μ A...., uPA.... : μ PA....
uPB.... : μ PB...., uPC.... : μ PC....
uPD.... : μ PD....
- CAPACITORS
uF : μ F
- COILS
uH : μ H

The components identified by mark Δ or dotted line with mark Δ are critical for safety.
Replace only with part number specified.

When indicating parts by reference number, please include the board.

- Abbreviation
G : German
SP : Singapore
CH : Chinese

| Ref.No. | Part No. | Description | Remark |
|-----------------|--------------|--|---------|
| * | A-4378-436-A | AC BOARD, COMPLETE (AEP, G, SP, CH) | |
| * | A-4378-437-A | AC BOARD, COMPLETE (UK) | |
| * | A-4378-438-A | AC BOARD, COMPLETE (E) | |
| | | ***** | |
| | | < BASE POST > | |
| * BP901 | 1-535-139-00 | BASE POST 19MM (10MM PITCH) 2P | |
| | | < CAPACITOR > | |
| Δ C901 | 1-161-744-51 | CERAMIC 0.01uF | 400V |
| Δ C902 | 1-161-744-51 | CERAMIC 0.01uF | 400V |
| C903 | 1-164-096-11 | CERAMIC 0.01uF | 50V |
| C904 | 1-124-557-11 | ELECT 1000uF | 20% 25V |
| C905 | 1-124-907-11 | ELECT 10uF | 20% 50V |
| C906 | 1-124-903-11 | ELECT 1uF | 20% 50V |
| C907 | 1-124-907-11 | ELECT 10uF | 20% 50V |
| C908 | 1-124-464-11 | ELECT 0.22uF | 20% 50V |
| C937 | 1-164-096-11 | CERAMIC 0.01uF | 50V |
| | | < JACK > | |
| Δ CNJ901 | 1-540-043-21 | OUTLET, AC (AC OUTLET) (NONPOLAR) (3P) (E) | |
| | | < CONNECTOR > | |
| CNP930 | 1-695-087-11 | PIN, CONNECTOR (PC BOARD) 7P | |
| CNV901 | 1-774-108-11 | PIN, CONNECTOR (PC BOARD) | |
| CNV902 | 1-564-321-00 | PIN, CONNECTOR 2P | |
| * CNV909 | 1-564-321-21 | PIN, CONNECTOR 2P (E) | |
| * CNV910 | 1-564-321-21 | PIN, CONNECTOR 2P (AEP, G, SP, CH) | |
| CNV911 | 1-564-321-00 | PIN, CONNECTOR 2P (E) | |
| | | < DIODE > | |
| D901 | 8-719-987-63 | DIODE 1N4148M | |

| Ref.No. | Part No. | Description | Remark |
|---------------|--------------|-------------------------------------|--------|
| D902 | 8-719-987-63 | DIODE 1N4148M | |
| D903-906 | | | |
| | 8-719-200-02 | DIODE 10E2 | |
| D907 | 8-719-987-63 | DIODE 1N4148M | |
| D908 | 8-719-933-41 | DIODE HZS6C3L | |
| D909 | 8-719-933-41 | DIODE HZS6C3L | |
| D910 | 8-719-010-23 | DIODE UZ-3.6BSB | |
| | | < TERMINAL BOARD > | |
| E99 | 1-537-770-21 | TERMINAL BOARD, GROUND | |
| | | < FUSE > | |
| Δ F2 | 1-532-286-00 | FUSE (T2.5AL/250V) (AEP, G, SP, CH) | |
| Δ F3 | 1-532-286-00 | FUSE (T2.5AL/250V) (E) | |
| | | < TRANSISTOR > | |
| Q901 | 8-729-620-05 | TRANSISTOR 2SC2603-EF | |
| Q902 | 8-729-209-15 | TRANSISTOR 2SD2012 | |
| Q903 | 8-729-119-76 | TRANSISTOR 2SA1175-HFE | |
| Q904 | 8-729-620-05 | TRANSISTOR 2SC2603-EF | |
| Q905 | 8-729-119-76 | TRANSISTOR 2SA1175-HFE | |
| Q906 | 8-729-620-05 | TRANSISTOR 2SC2603-EF | |
| | | < RESISTOR > | |
| Δ R900 | 1-212-950-00 | FUSIBLE 4.7 5% 1/2W F | |
| R901 | 1-249-425-11 | CARBON 4.7K 5% 1/4W | |
| R902 | 1-249-396-11 | CARBON 18 5% 1/4W | |
| R903 | 1-249-417-11 | CARBON 1K 5% 1/4W | |
| R904 | 1-249-436-11 | CARBON 39K 5% 1/4W | |
| R905 | 1-249-429-11 | CARBON 10K 5% 1/4W | |
| R906 | 1-249-426-11 | CARBON 5.6K 5% 1/4W | |
| R907 | 1-249-429-11 | CARBON 10K 5% 1/4W | |
| R908 | 1-249-426-11 | CARBON 5.6K 5% 1/4W | |

AC

AMP

| Ref. No. | Part No. | Description | Remark | | |
|-----------------|--------------|---|---------|--------|------|
| R909 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W |
| R910 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W |
| R913 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W |
| R914 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W |
| < RELAY > | | | | | |
| △RY901 | 1-515-701-11 | RELAY | | | |
| < TRANSFORMER > | | | | | |
| △T901 | 1-449-071-21 | TRANSFORMER, POWER (AEP, UK, G, SP, CH) | | | |
| △T901 | 1-448-523-11 | TRANSFORMER, POWER (E) | | | |
| ***** | | | | | |
| * | A-4378-440-A | AMP BOARD, COMPLETE | | | |
| ***** | | | | | |
| < BASE POST > | | | | | |
| * BP001 | 1-535-115-00 | TERMINAL | | | |
| * BP501 | 1-535-115-00 | TERMINAL | | | |
| * BP551 | 1-535-115-00 | TERMINAL | | | |
| < CAPACITOR > | | | | | |
| C001 | 1-126-963-11 | ELECT | 4.7uF | 20% | 50V |
| C002 | 1-164-077-11 | CERAMIC | 220PF | 10% | 50V |
| C003 | 1-110-339-11 | MYLAR | 220PF | 5% | 50V |
| C004 | 1-124-477-11 | ELECT | 47uF | 20% | 25V |
| C005 | 1-164-039-11 | CERAMIC | 3PF | 0.25PF | 50V |
| C006 | 1-124-120-11 | ELECT | 220uF | 20% | 25V |
| C008 | 1-124-477-11 | ELECT | 47uF | 20% | 25V |
| C009 | 1-107-597-11 | CERAMIC | 22PF | 10% | 500V |
| C011 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C501 | 1-126-963-11 | ELECT | 4.7uF | 20% | 50V |
| C502 | 1-164-077-11 | CERAMIC | 220PF | 10% | 50V |
| C503 | 1-130-471-00 | MYLAR | 0.001uF | 5% | 50V |
| C504 | 1-124-477-11 | ELECT | 47uF | 20% | 25V |
| C505 | 1-164-039-11 | CERAMIC | 3PF | 0.25PF | 50V |
| C506 | 1-124-120-11 | ELECT | 220uF | 20% | 25V |
| C508 | 1-124-477-11 | ELECT | 47uF | 20% | 25V |
| C509 | 1-107-597-11 | CERAMIC | 22PF | 10% | 500V |
| C511 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |
| C551 | 1-126-963-11 | ELECT | 4.7uF | 20% | 50V |
| C552 | 1-164-077-11 | CERAMIC | 220PF | 10% | 50V |
| C553 | 1-130-471-00 | MYLAR | 0.001uF | 5% | 50V |
| C554 | 1-124-477-11 | ELECT | 47uF | 20% | 25V |
| C555 | 1-164-039-11 | CERAMIC | 3PF | 0.25PF | 50V |
| C556 | 1-124-120-11 | ELECT | 220uF | 20% | 25V |
| C558 | 1-124-477-11 | ELECT | 47uF | 20% | 25V |
| C559 | 1-107-597-11 | CERAMIC | 22PF | 10% | 500V |
| C561 | 1-136-165-00 | FILM | 0.1uF | 5% | 50V |

| Ref. No. | Part No. | Description | Remark | | |
|----------|--------------|-------------|---------|-----|-----|
| C601 | 1-126-963-11 | ELECT | 4.7uF | 20% | 50V |
| C602 | 1-162-282-31 | CERAMIC | 100PF | 10% | 50V |
| C603 | 1-162-282-31 | CERAMIC | 100PF | 10% | 50V |
| C604 | 1-162-191-31 | CERAMIC | 2.2PF | 10% | 50V |
| C605 | 1-124-443-00 | ELECT | 100uF | 20% | 10V |
| C606 | 1-136-163-00 | FILM | 0.068uF | 5% | 50V |
| C607 | 1-136-163-00 | FILM | 0.068uF | 5% | 50V |
| C651 | 1-126-963-11 | ELECT | 4.7uF | 20% | 50V |
| C652 | 1-162-282-31 | CERAMIC | 100PF | 10% | 50V |
| C653 | 1-162-282-31 | CERAMIC | 100PF | 10% | 50V |
| C654 | 1-162-191-31 | CERAMIC | 2.2PF | 10% | 50V |
| C655 | 1-124-443-00 | ELECT | 100uF | 20% | 10V |
| C656 | 1-136-163-00 | FILM | 0.068uF | 5% | 50V |
| C657 | 1-136-163-00 | FILM | 0.068uF | 5% | 50V |

< CONNECTOR >

| | | | | | |
|------------|--------------|---------------------------|--|--|--|
| CNE35 | 1-691-771-11 | PLUG (MICRO CONNECTOR) 9P | | | |
| * CNS51-54 | 1-750-533-11 | SOCKET 6P | | | |

< DIODE >

| | | | | | |
|------|--------------|-------|------------|--|--|
| D001 | 8-719-002-83 | DIODE | US1090M-TP | | |
| D002 | 8-719-933-35 | DIODE | HZS6A3L | | |
| D008 | 8-719-002-83 | DIODE | US1090M-TP | | |
| D501 | 8-719-002-83 | DIODE | US1090M-TP | | |
| D502 | 8-719-933-35 | DIODE | HZS6A3L | | |
| D508 | 8-719-002-83 | DIODE | US1090M-TP | | |
| D551 | 8-719-002-83 | DIODE | US1090M-TP | | |
| D552 | 8-719-933-35 | DIODE | HZS6A3L | | |
| D558 | 8-719-002-83 | DIODE | US1090M-TP | | |

< IC >



| | | | | | |
|-------|--------------|----|----------|--|--|
| IC601 | 8-759-085-89 | IC | LM3875-S | | |
| IC651 | 8-759-085-89 | IC | LM3875-S | | |

< COIL >

| | | | | | |
|--------|--------------|----------------|--|--|--|
| * L601 | 1-420-872-00 | COIL, AIR-CORE | | | |
| * L651 | 1-420-872-00 | COIL, AIR-CORE | | | |

< TRANSISTOR >

| | | | | | |
|------|--------------|------------|---------------|--|--|
| Q001 | 8-729-620-18 | TRANSISTOR | 2SA979-FG | | |
| Q002 | 8-729-140-82 | TRANSISTOR | 2SA988-PAFAEA | | |
| Q003 | 8-729-119-79 | TRANSISTOR | 2SC2785-FEK | | |
| Q004 | 8-729-201-56 | TRANSISTOR | 2SK246-GR2 | | |
| Q005 | 8-729-119-79 | TRANSISTOR | 2SC2785-FEK | | |
| Q006 | 8-729-802-71 | TRANSISTOR | 2SA1407-D | | |
| Q007 | 8-729-805-05 | TRANSISTOR | 2SC3601-E | | |
| Q008 | 8-729-119-76 | TRANSISTOR | 2SA1175-HFE | | |
| Q009 | 8-729-141-30 | TRANSISTOR | 2SC3623A-LK | | |

The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.

| Ref. No. | Part No. | Description | Remark |
|--------------|--------------|--------------------------|--------|
| Q011 | 8-729-020-52 | TRANSISTOR 2SD2439-OPY | |
| Q013 | 8-729-020-48 | TRANSISTOR 2SB1588-OPY | |
| Q015 | 8-729-140-82 | TRANSISTOR 2SA988-PAFAEA | |
| Q501 | 8-729-620-18 | TRANSISTOR 2SA979-FG | |
| Q502 | 8-729-140-82 | TRANSISTOR 2SA988-PAFAEA | |
| Q503 | 8-729-119-79 | TRANSISTOR 2SC2785-FEK | |
| Q504 | 8-729-201-56 | TRANSISTOR 2SK246-GR2 | |
| Q505 | 8-729-119-79 | TRANSISTOR 2SC2785-FEK | |
| Q506 | 8-729-802-71 | TRANSISTOR 2SA1407-D | |
| Q507 | 8-729-805-05 | TRANSISTOR 2SC3601-E | |
| Q508 | 8-729-119-76 | TRANSISTOR 2SA1175-HFE | |
| Q509 | 8-729-141-30 | TRANSISTOR 2SC3623A-LK | |
| Q511 | 8-729-020-52 | TRANSISTOR 2SD2439-OPY | |
| Q513 | 8-729-020-48 | TRANSISTOR 2SB1588-OPY | |
| Q515 | 8-729-140-82 | TRANSISTOR 2SA988-PAFAEA | |
| Q551 | 8-729-620-18 | TRANSISTOR 2SA979-FG | |
| Q552 | 8-729-140-82 | TRANSISTOR 2SA988-PAFAEA | |
| Q553 | 8-729-119-79 | TRANSISTOR 2SC2785-FEK | |
| Q554 | 8-729-201-56 | TRANSISTOR 2SK246-GR2 | |
| Q555 | 8-729-119-79 | TRANSISTOR 2SC2785-FEK | |
| Q556 | 8-729-802-71 | TRANSISTOR 2SA1407-D | |
| Q557 | 8-729-805-05 | TRANSISTOR 2SC3601-E | |
| Q558 | 8-729-119-76 | TRANSISTOR 2SA1175-HFE | |
| Q559 | 8-729-141-30 | TRANSISTOR 2SC3623A-LK | |
| Q561 | 8-729-020-52 | TRANSISTOR 2SD2439-OPY | |
| Q563 | 8-729-020-48 | TRANSISTOR 2SB1588-OPY | |
| Q565 | 8-729-140-82 | TRANSISTOR 2SA988-PAFAEA | |
| < RESISTOR > | | | |
| R001 | 1-249-417-11 | CARBON 1K 5% | 1/4W |
| R002 | 1-249-437-11 | CARBON 47K 5% | 1/4W |
| R003 | 1-249-413-11 | CARBON 470 5% | 1/4W |
| △R004 | 1-212-889-00 | FUSIBLE 220 5% | 1/4W F |
| △R005 | 1-212-889-00 | FUSIBLE 220 5% | 1/4W F |
| R006 | 1-249-421-11 | CARBON 2.2K 5% | 1/4W |
| R007 | 1-249-429-11 | CARBON 10K 5% | 1/4W |
| R008 | 1-249-435-11 | CARBON 33K 5% | 1/4W |
| R009 | 1-249-433-11 | CARBON 22K 5% | 1/4W |
| R010 | 1-249-492-11 | CARBON 47K 5% | 1/2W |
| R011 | 1-247-747-11 | CARBON 470 5% | 1/2W |
| R012 | 1-249-411-11 | CARBON 330 5% | 1/4W |
| R013 | 1-249-431-11 | CARBON 15K 5% | 1/4W |
| △R014 | 1-212-865-00 | FUSIBLE 22 5% | 1/4W F |
| △R015 | 1-212-865-00 | FUSIBLE 22 5% | 1/4W F |
| R016 | 1-249-439-11 | CARBON 68K 5% | 1/4W |
| R017 | 1-249-421-11 | CARBON 2.2K 5% | 1/4W |
| R018 | 1-249-414-11 | CARBON 560 5% | 1/4W |
| R019 | 1-249-431-11 | CARBON 15K 5% | 1/4W |
| △R020 | 1-212-857-00 | FUSIBLE 10 5% | 1/4W F |

| Ref. No. | Part No. | Description | Remark |
|----------|--------------|-----------------------------|--------|
| △R021 | 1-212-857-00 | FUSIBLE 10 5% | 1/4W F |
| △R022 | 1-239-912-21 | ENCAPSULATED COMPONENT 0.22 | |
| R025 | 1-249-425-11 | CARBON 4.7K 5% | 1/4W |
| R027 | 1-249-421-11 | CARBON 2.2K 5% | 1/4W |
| R029 | 1-249-431-11 | CARBON 15K 5% | 1/4W |
| R501 | 1-249-417-11 | CARBON 1K 5% | 1/4W |
| R502 | 1-249-435-11 | CARBON 33K 5% | 1/4W |
| R503 | 1-249-407-11 | CARBON 150 5% | 1/4W |
| △R504 | 1-212-889-00 | FUSIBLE 220 5% | 1/4W F |
| △R505 | 1-212-889-00 | FUSIBLE 220 5% | 1/4W F |
| R506 | 1-249-421-11 | CARBON 2.2K 5% | 1/4W |
| R507 | 1-249-429-11 | CARBON 10K 5% | 1/4W |
| R508 | 1-249-435-11 | CARBON 33K 5% | 1/4W |
| R509 | 1-249-433-11 | CARBON 22K 5% | 1/4W |
| R510 | 1-247-765-11 | CARBON 33K 5% | 1/2W |
| R511 | 1-247-758-11 | CARBON 3.3K 5% | 1/2W |
| R512 | 1-249-411-11 | CARBON 330 5% | 1/4W |
| R513 | 1-249-431-11 | CARBON 15K 5% | 1/4W |
| △R514 | 1-212-865-00 | FUSIBLE 22 5% | 1/4W F |
| △R515 | 1-212-865-00 | FUSIBLE 22 5% | 1/4W F |
| R516 | 1-249-439-11 | CARBON 68K 5% | 1/4W |
| R517 | 1-249-421-11 | CARBON 2.2K 5% | 1/4W |
| R518 | 1-249-414-11 | CARBON 560 5% | 1/4W |
| R519 | 1-249-431-11 | CARBON 15K 5% | 1/4W |
| △R520 | 1-212-857-00 | FUSIBLE 10 5% | 1/4W F |
| △R521 | 1-212-857-00 | FUSIBLE 10 5% | 1/4W F |
| △R522 | 1-239-912-21 | ENCAPSULATED COMPONENT 0.22 | |
| R525 | 1-249-425-11 | CARBON 4.7K 5% | 1/4W |
| R527 | 1-249-421-11 | CARBON 2.2K 5% | 1/4W |
| R529 | 1-249-431-11 | CARBON 15K 5% | 1/4W |
| R551 | 1-249-417-11 | CARBON 1K 5% | 1/4W |
| R552 | 1-249-435-11 | CARBON 33K 5% | 1/4W |
| R553 | 1-249-407-11 | CARBON 150 5% | 1/4W |
| △R554 | 1-212-889-00 | FUSIBLE 220 5% | 1/4W F |
| △R555 | 1-212-889-00 | FUSIBLE 220 5% | 1/4W F |
| R556 | 1-249-421-11 | CARBON 2.2K 5% | 1/4W |
| R557 | 1-249-429-11 | CARBON 10K 5% | 1/4W |
| R558 | 1-249-435-11 | CARBON 33K 5% | 1/4W |
| R559 | 1-249-433-11 | CARBON 22K 5% | 1/4W |
| R560 | 1-247-765-11 | CARBON 33K 5% | 1/2W |
| R561 | 1-247-758-11 | CARBON 3.3K 5% | 1/2W |
| R562 | 1-249-411-11 | CARBON 330 5% | 1/4W |
| R563 | 1-249-431-11 | CARBON 15K 5% | 1/4W |
| △R564 | 1-212-865-00 | FUSIBLE 22 5% | 1/4W |
| △R565 | 1-212-865-00 | FUSIBLE 22 5% | 1/4W |
| R566 | 1-249-439-11 | CARBON 68K 5% | 1/4W |
| R567 | 1-249-421-11 | CARBON 2.2K 5% | 1/4W |
| R568 | 1-249-414-11 | CARBON 560 5% | 1/4W |
| R569 | 1-249-431-11 | CARBON 15K 5% | 1/4W |

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

| | | | | |
|-----|-----|-----|-----|-----|
| AMP | CNA | CNB | CND | CNL |
|-----|-----|-----|-----|-----|

| Ref. No. | Part No. | Description | Remark | |
|----------|--------------|------------------------------------|-----------|--------|
| △R570 | 1-212-857-00 | FUSIBLE | 10 5% | 1/4W F |
| △R571 | 1-212-857-00 | FUSIBLE | 10 5% | 1/4W F |
| △R572 | 1-239-912-21 | ENCAPSULATED COMPONENT | 0.22 | |
| R575 | 1-249-425-11 | CARBON | 4.7K 5% | 1/4W |
| R577 | 1-249-421-11 | CARBON | 2.2K 5% | 1/4W |
| R579 | 1-249-431-11 | CARBON | 15K 5% | 1/4W |
| R601 | 1-249-417-11 | CARBON | 1K 5% | 1/4W |
| R602 | 1-249-438-11 | CARBON | 56K 5% | 1/4W |
| R604 | 1-249-438-11 | CARBON | 56K 5% | 1/4W |
| R605 | 1-249-414-11 | CARBON | 560 5% | 1/4W |
| R607 | 1-247-727-11 | CARBON | 10 5% | 1/2W |
| R608 | 1-247-727-11 | CARBON | 10 5% | 1/2W |
| R651 | 1-249-417-11 | CARBON | 1K 5% | 1/4W |
| R652 | 1-249-438-11 | CARBON | 56K 5% | 1/4W |
| R654 | 1-249-438-11 | CARBON | 56K 5% | 1/4W |
| R655 | 1-249-414-11 | CARBON | 560 5% | 1/4W |
| R657 | 1-247-727-11 | CARBON | 10 5% | 1/2W |
| R658 | 1-247-727-11 | CARBON | 10 5% | 1/2W |
| ***** | | | | |
| * | 1-657-062-11 | CNA BOARD | ***** | |
| | | < CAPACITOR > | | |
| C701 | 1-126-941-11 | ELECT | 470uF 20% | 6.3V |
| C702 | 1-136-165-00 | FILM | 0.1uF 5% | 50V |
| | | < CONNECTOR > | | |
| * CNE38 | 1-564-518-11 | PLUG, CONNECTOR 3P | | |
| CNE925 | 1-564-517-11 | PLUG, CONNECTOR 2P | | |
| CNFB82 | 1-766-100-11 | CONNECTOR, FFC (LIF (NON-ZIF)) 15P | | |
| CNS71 | 1-695-092-11 | SOCKET, CONNECTOR 7P | | |
| CNS72 | 1-695-092-11 | SOCKET, CONNECTOR 7P | | |
| CNS73 | 1-750-179-11 | SOCKET, CONNECTOR 5P | | |
| CNS931 | 1-695-092-11 | SOCKET, CONNECTOR 7P | | |
| | | < DIODE > | | |
| D701-703 | 8-719-002-83 | DIODE US1090M-TP | | |
| D704 | 8-719-200-02 | DIODE 10E2 | | |
| D710 | 8-719-987-63 | DIODE 1N4148M | | |
| D711 | 8-719-987-63 | DIODE 1N4148M | | |
| D720 | 8-719-987-63 | DIODE 1N4148M | | |
| D721 | 8-719-987-63 | DIODE 1N4148M | | |
| D725 | 8-719-987-63 | DIODE 1N4148M | | |
| D726 | 8-719-987-63 | DIODE 1N4148M | | |
| | | < TRANSISTOR > | | |
| Q701 | 8-729-140-82 | TRANSISTOR 2SA988-PAFAEA | | |

| Ref.No. | Part No. | Description | Remark | | |
|---------|--------------|------------------------------|----------------|----|------|
| Q702 | 8-729-620-05 | TRANSISTOR | 2SC2603-EF | | |
| Q703 | 8-729-140-84 | TRANSISTOR | 2SC1841-PAFAEA | | |
| Q710 | 8-729-620-05 | TRANSISTOR | 2SC2603-EF | | |
| Q715 | 8-729-620-05 | TRANSISTOR | 2SC2603-EF | | |
| Q720 | 8-729-620-05 | TRANSISTOR | 2SC2603-EF | | |
| Q725 | 8-729-620-05 | TRANSISTOR | 2SC2603-EF | | |
| | | < RESISTOR > | | | |
| R701 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W |
| R702 | 1-249-427-11 | CARBON | 6.8K | 5% | 1/4W |
| R703 | 1-249-435-11 | CARBON | 33K | 5% | 1/4W |
| R710 | 1-249-425-11 | CARBON | 4.7K | 5% | 1/4W |
| R711 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W |
| R715 | 1-249-425-11 | CARBON | 4.7K | 5% | 1/4W |
| R716 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W |
| R718 | 1-247-754-11 | CARBON | 1.5K | 5% | 1/2W |
| R721 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W |
| R726 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W |
| R728 | 1-247-743-11 | CARBON | 220 | 5% | 1/2W |
| ***** | | | | | |
| * | 1-657-066-11 | CNB BOARD | ***** | | |
| | | < CONNECTOR > | | | |
| CNS940 | 1-750-179-11 | SOCKET, CONNECTOR 5P | | | |
| CNS941 | 1-750-179-11 | SOCKET, CONNECTOR 5P | | | |
| ***** | | | | | |
| * | 1-657-069-11 | CND BOARD | ***** | | |
| | | < CONNECTOR > | | | |
| CNS21 | 1-695-094-11 | SOCKET, CONNECTOR 11P | | | |
| CNS23 | 1-695-094-11 | SOCKET, CONNECTOR 11P | | | |
| ***** | | | | | |
| * | 1-657-059-11 | CNL BOARD | ***** | | |
| | | < CONNECTOR > | | | |
| CNP32 | 1-695-088-11 | PIN, CONNECTOR (PC BOARD) 9P | | | |
| CNS31 | 1-695-093-11 | SOCKET, CONNECTOR 9P | | | |
| ***** | | | | | |

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

CNP

CNT 1

CNT 2

HP

MAIN

| Ref. No. | Part No. | Description | Remark |
|----------|---------------------|--------------------------------|--------|
| * | 1-657-365-11 | CNP BOARD ***** | |
| | | < CONNECTOR > | |
| | CNP931 1-695-087-11 | PIN, CONNECTOR (PC BOARD) 7P | |
| | CNS930 1-695-092-11 | SOCKET, CONNECTOR 7P | |
| ***** | | | |
| * | 1-657-063-11 | CNT1 BOARD ***** | |
| | | < CONNECTOR > | |
| | CNV903 1-690-123-21 | REED (WITH CONNECTOR) (2 CORE) | |
| | CNV912 1-568-106-11 | PIN, CONNECTOR 4P (E) | |
| | | < FUSE > | |
| △F1 | 1-532-286-00 | FUSE (T2.5AL/250V) | |
| ***** | | | |
| * | 1-657-064-11 | CNT2 BOARD ***** | |
| | | < CONNECTOR > | |
| | CNE922 1-564-505-11 | PLUG, CONNECTOR 2P | |
| * | CNV920 1-564-104-00 | PIN, CONNECTOR (B3P-VH) 3P | |
| * | CNV921 1-564-242-00 | PIN, CONNECTOR 5P | |
| | | < FUSE > | |
| △F901 | 1-532-299-00 | FUSE (T5AL/250V) | |
| △F902 | 1-532-299-00 | FUSE (T5AL/250V) | |
| | | < RESISTOR > | |
| △R916 | 1-217-469-00 | FUSIBLE 1 5% 1W F | |
| △R917 | 1-217-469-00 | FUSIBLE 1 5% 1W F | |
| ***** | | | |
| * | 1-657-056-11 | HP BOARD ***** | |
| | | < CONNECTOR > | |
| * | CNE39 1-564-506-11 | PLUG, CONNECTOR 3P | |
| | | < JACK > | |
| J501 | 1-507-796-71 | JACK (PHONES) | |
| ***** | | | |
| * | A-4378-447-A | MAIN BOARD, COMPLETE ***** | |
| * | 1-535-730-21 | LEAD, JUMPER (OFC) | |

| Ref. No. | Part No. | Description | Remark |
|---------------|--------------|----------------|---------|
| < CAPACITOR > | | | |
| C101 | 1-164-072-11 | CERAMIC 120PF | 5% 50V |
| C102 | 1-124-907-11 | ELECT 10uF | 20% 50V |
| C103 | 1-164-070-11 | CERAMIC 100PF | 5% 50V |
| C104 | 1-104-664-11 | ELECT 47uF | 20% 16V |
| C105 | 1-130-480-00 | MYLAR 0.0056uF | 5% 50V |
| C106 | 1-130-473-00 | MYLAR 0.0015uF | 5% 50V |
| C107 | 1-124-903-11 | ELECT 1uF | 20% 50V |
| C108 | 1-124-910-11 | ELECT 47uF | 20% 50V |
| C140 | 1-136-153-00 | FILM 0.01uF | 5% 50V |
| C151 | 1-164-072-11 | CERAMIC 120PF | 5% 50V |
| C152 | 1-124-907-11 | ELECT 10uF | 20% 50V |
| C153 | 1-164-070-11 | CERAMIC 100PF | 5% 50V |
| C154 | 1-104-664-11 | ELECT 47uF | 20% 16V |
| C155 | 1-130-480-00 | MYLAR 0.0056uF | 5% 50V |
| C156 | 1-130-473-00 | MYLAR 0.0015uF | 5% 50V |
| C157 | 1-124-903-11 | ELECT 1uF | 20% 50V |
| C158 | 1-124-910-11 | ELECT 47uF | 20% 50V |
| C170 | 1-164-159-11 | CERAMIC 0.1uF | 50V |
| C171 | 1-164-159-11 | CERAMIC 0.1uF | 50V |
| C303 | 1-136-157-00 | FILM 0.022uF | 5% 50V |
| C304 | 1-136-161-00 | FILM 0.047uF | 5% 50V |
| C305 | 1-104-666-11 | ELECT 220uF | 20% 10V |
| C306-309 | | | |
| | 1-124-907-11 | ELECT 10uF | 20% 50V |
| C310 | 1-104-666-11 | ELECT 220uF | 20% 10V |
| C311 | 1-126-963-11 | ELECT 4.7uF | 20% 50V |
| C312 | 1-126-963-11 | ELECT 4.7uF | 20% 50V |
| C313 | 1-136-165-00 | FILM 0.1uF | 5% 50V |
| C314 | 1-136-165-00 | FILM 0.1uF | 5% 50V |
| C315 | 1-124-902-00 | ELECT 0.47uF | 20% 50V |
| C316 | 1-126-963-11 | ELECT 4.7uF | 20% 50V |
| C317 | 1-124-902-00 | ELECT 0.47uF | 20% 50V |
| C318 | 1-126-963-11 | ELECT 4.7uF | 20% 50V |
| C319 | 1-124-250-11 | ELECT 0.15uF | 20% 50V |
| C320 | 1-126-962-11 | ELECT 3.3uF | 20% 50V |
| C321 | 1-124-250-11 | ELECT 0.15uF | 20% 50V |
| C322 | 1-162-282-31 | CERAMIC 100PF | 10% 50V |
| C323 | 1-104-664-11 | ELECT 47uF | 20% 16V |
| C324 | 1-136-165-00 | FILM 0.1uF | 5% 50V |
| C325 | 1-136-165-00 | FILM 0.1uF | 5% 50V |
| C326 | 1-124-902-00 | ELECT 0.47uF | 20% 50V |
| C327 | 1-126-963-11 | ELECT 4.7uF | 20% 50V |
| C328 | 1-126-963-11 | ELECT 4.7uF | 20% 50V |
| C329 | 1-124-250-11 | ELECT 0.15uF | 20% 50V |
| C330 | 1-124-902-00 | ELECT 0.47uF | 20% 50V |
| C331 | 1-126-962-11 | ELECT 3.3uF | 20% 50V |
| C332 | 1-124-250-11 | ELECT 0.15uF | 20% 50V |

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

MAIN

| Ref. No. | Part No. | Description | Remark |
|--------------------|--------------|----------------------------------|----------|
| C333 | 1-104-666-11 | ELECT 220uF | 20% 10V |
| C334 | 1-104-664-11 | ELECT 47uF | 20% 16V |
| C335 | 1-164-159-11 | CERAMIC 0.1uF | 50V |
| C336 | 1-124-925-11 | ELECT 2.2uF | 20% 100V |
| C337 | 1-104-666-11 | ELECT 220uF | 20% 10V |
| C338 | 1-136-159-00 | FILM 0.033uF | 5% 50V |
| C339 | 1-124-907-11 | ELECT 10uF | 20% 50V |
| C340 | 1-130-469-00 | MYLAR 680PF | 5% 50V |
| C341 | 1-126-963-11 | ELECT 4.7uF | 20% 50V |
| C342 | 1-126-963-11 | ELECT 4.7uF | 20% 50V |
| C344 | 1-126-963-11 | ELECT 4.7uF | 20% 50V |
| C346 | 1-164-159-11 | CERAMIC 0.1uF | 50V |
| C347 | 1-136-173-00 | FILM 0.47uF | 5% 50V |
| C351 | 1-164-159-11 | CERAMIC 0.1uF | 50V |
| C352 | 1-104-666-11 | ELECT 220uF | 20% 10V |
| C353 | 1-136-159-00 | FILM 0.033uF | 5% 50V |
| C354 | 1-130-473-00 | MYLAR 0.0015uF | 5% 50V |
| C355 | 1-136-159-00 | FILM 0.033uF | 5% 50V |
| C356 | 1-124-903-11 | ELECT 1uF | 20% 50V |
| C357 | 1-104-666-11 | ELECT 220uF | 20% 10V |
| C358 | 1-164-159-11 | CERAMIC 0.1uF | 50V |
| C391 | 1-126-963-11 | ELECT 4.7uF | 20% 50V |
| C392 | 1-126-963-11 | ELECT 4.7uF | 20% 50V |
| C394 | 1-126-963-11 | ELECT 4.7uF | 20% 50V |
| C398 | 1-136-165-00 | FILM 0.1uF | 5% 50V |
| C929 | 1-124-910-11 | ELECT 47uF | 20% 50V |
| C930 | 1-124-910-11 | ELECT 47uF | 20% 50V |
| C934-936 | 1-126-941-11 | ELECT 470uF | 20% 16V |
| C938 | 1-136-165-00 | FILM 0.1uF | 5% 50V |
| < CONNECTOR > | | | |
| * CNE28 | 1-564-506-11 | PLUG, CONNECTOR 3P | |
| CNFB81 | 1-764-958-11 | CONNECTOR, FFC(LIF(NON-ZIF)) 17P | |
| CNP23 | 1-695-089-11 | PIN, CONNECTOR (PC BOARD) 11P | |
| CNP31 | 1-695-088-11 | PIN, CONNECTOR (PC BOARD) 9P | |
| CNP941 | 1-750-180-11 | PIN, CONNECTOR (PC BOARD) 5P | |
| * CNS11 | 1-691-746-11 | CONNECTOR, BOARD TO BOARD 5P | |
| < DIODE > | | | |
| D301 | 8-719-001-30 | DIODE UZL-9H3 | |
| D815 | 8-719-985-41 | DIODE HZS2CLL | |
| < TERMINAL BOARD > | | | |
| E31 | 1-537-770-21 | TERMINAL BOARD, GROUND | |
| < IC > | | | |
| IC101 | 8-759-184-02 | IC NJM2068L-D | |

| Ref. No. | Part No. | Description | Remark |
|----------------|--------------|-----------------------------------|--------|
| IC102 | 8-759-634-50 | IC M5218AL | |
| IC103 | 8-759-634-51 | IC M5218AP | |
| IC104 | 8-759-805-14 | IC LC7822 | |
| IC105 | 8-759-805-14 | IC LC7822 | |
| IC301 | 8-759-248-74 | IC LA2785 | |
| IC302 | 8-759-341-23 | IC LV1011 | |
| IC303 | 8-759-634-51 | IC M5218AP | |
| IC304 | 8-759-801-01 | IC LC4966 | |
| IC921 | 8-759-231-58 | IC TA7812S | |
| IC922 | 8-759-245-86 | IC TA7912S | |
| IC923 | 8-759-231-53 | IC TA7805S | |
| < JACK > | | | |
| J101 | 1-565-258-11 | JACK, PIN 4P (PHONO/TUNER) | |
| J102 | 1-565-320-61 | JACK, PIN 6P (CD/AUX/TAPE OUT) | |
| J103 | 1-565-320-61 | JACK, PIN 6P (VIDEO 3/LD/TAPE IN) | |
| J104 | 1-565-258-11 | JACK, PIN 4P (VIDEO 2) | |
| J105 | 1-565-258-11 | JACK, PIN 4P (VIDEO 1) | |
| J106 | 1-750-595-11 | JACK, PIN 4P (OUT) | |
| < COIL > | | | |
| L301 | 1-410-509-11 | INDUCTOR 10uH | |
| L302 | 1-410-509-11 | INDUCTOR 10uH | |
| < TRANSISTOR > | | | |
| Q303 | 8-729-140-96 | TRANSISTOR 2SD774-34 | |
| Q304-307 | 8-729-141-30 | TRANSISTOR 2SC3623A-LK | |
| Q308 | 8-729-900-63 | TRANSISTOR DTA124ES | |
| < RESISTOR > | | | |
| R101 | 1-249-411-11 | CARBON 330 5% 1/4W | |
| R102-105 | 1-249-417-11 | CARBON 1K 5% 1/4W | |
| R106 | 1-249-421-11 | CARBON 2.2K 5% 1/4W | |
| R107 | 1-249-429-11 | CARBON 10K 5% 1/4W | |
| R108-113 | 1-249-417-11 | CARBON 1K 5% 1/4W | |
| R115 | 1-249-441-11 | CARBON 100K 5% 1/4W | |
| R116 | 1-249-441-11 | CARBON 100K 5% 1/4W | |
| R117 | 1-249-416-11 | CARBON 820 5% 1/4W | |
| R118 | 1-247-897-11 | CARBON 560K 5% 1/4W | |
| R119 | 1-249-437-11 | CARBON 47K 5% 1/4W | |
| R120 | 1-249-441-11 | CARBON 100K 5% 1/4W | |
| R121 | 1-249-409-11 | CARBON 220 5% 1/4W | |
| R122 | 1-249-409-11 | CARBON 220 5% 1/4W | |
| R128 | 1-249-425-11 | CARBON 4.7K 5% 1/4W | |
| R130 | 1-249-437-11 | CARBON 47K 5% 1/4W | |

| Ref. No. | Part No. | Description | Remark | | |
|----------|--------------|-------------|--------|----|--------|
| R131 | 1-249-437-11 | CARBON | 47K | 5% | 1/4W |
| R142 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W |
| R151 | 1-249-411-11 | CARBON | 330 | 5% | 1/4W |
| R152-155 | | | | | |
| | 1-249-417-11 | CARBON | 1K | 5% | 1/4W |
| R156 | 1-249-421-11 | CARBON | 2. 2K | 5% | 1/4W |
| R157 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W |
| R158-163 | | | | | |
| | 1-249-417-11 | CARBON | 1K | 5% | 1/4W |
| R165 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W |
| R166 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W |
| R167 | 1-249-416-11 | CARBON | 820 | 5% | 1/4W |
| R168 | 1-247-897-11 | CARBON | 560K | 5% | 1/4W |
| R169 | 1-249-437-11 | CARBON | 47K | 5% | 1/4W |
| R170 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W |
| R171 | 1-249-409-11 | CARBON | 220 | 5% | 1/4W |
| R172 | 1-249-409-11 | CARBON | 220 | 5% | 1/4W |
| R180 | 1-249-437-11 | CARBON | 47K | 5% | 1/4W |
| R181 | 1-249-437-11 | CARBON | 47K | 5% | 1/4W |
| R307 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W |
| R308 | 1-249-431-11 | CARBON | 15K | 5% | 1/4W |
| R309 | 1-249-407-11 | CARBON | 150 | 5% | 1/4W |
| R310 | 1-249-436-11 | CARBON | 39K | 5% | 1/4W |
| R311 | 1-249-436-11 | CARBON | 39K | 5% | 1/4W |
| R312 | 1-247-903-00 | CARBON | 1M | 5% | 1/4W |
| R313 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W |
| R314 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W |
| R315 | 1-249-433-11 | CARBON | 22K | 5% | 1/4W |
| R316 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W |
| R317 | 1-249-425-11 | CARBON | 4. 7K | 5% | 1/4W |
| R318 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W |
| R319 | 1-249-425-11 | CARBON | 4. 7K | 5% | 1/4W |
| R320 | 1-249-437-11 | CARBON | 47K | 5% | 1/4W |
| R321 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W |
| R363 | 1-249-441-11 | CARBON | 100K | 5% | 1/4W |
| R364 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W |
| R365 | 1-249-429-11 | CARBON | 10K | 5% | 1/4W |
| R366 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W |
| R367 | 1-249-425-11 | CARBON | 4. 7K | 5% | 1/4W |
| R368 | 1-249-417-11 | CARBON | 1K | 5% | 1/4W |
| R369 | 1-249-425-11 | CARBON | 4. 7K | 5% | 1/4W |
| R371 | 1-249-437-11 | CARBON | 47K | 5% | 1/4W |
| △R923 | 1-212-962-00 | FUSIBLE | 15 | 5% | 1/2W F |
| △R924 | 1-217-489-00 | FUSIBLE | 47 | 5% | 1W F |
| △R927 | 1-212-962-00 | FUSIBLE | 15 | 5% | 1/2W F |

< VIBRATOR >

X301 1-579-952-21 VIBRATOR, CERAMIC (8MHz)

| Ref. No. | Part No. | Description | Remark | | |
|----------|--------------|--------------------------------|-------------------------|--------|-----|
| * | A-4378-427-A | PANEL BOARD, COMPLETE ***** | | | |
| | | < CAPACITOR > | | | |
| C402 | 1-164-159-11 | CERAMIC | 0. 1uF | | 50V |
| C403 | 1-126-963-11 | ELECT | 4. 7uF | 20% | 50V |
| C404 | 1-104-664-11 | ELECT | 47uF | 20% | 16V |
| C405 | 1-102-963-00 | CERAMIC | 33PF | 5% | 50V |
| C406 | 1-126-963-11 | ELECT | 4. 7uF | 20% | 50V |
| C407 | 1-130-481-00 | MYLAR | 0. 0068uF | 5% | 50V |
| C408 | 1-136-163-00 | FILM | 0. 068uF | 5% | 50V |
| C409 | 1-130-477-00 | MYLAR | 0. 0033uF | 5% | 50V |
| C410 | 1-136-159-00 | FILM | 0. 033uF | 5% | 50V |
| C452 | 1-164-159-11 | CERAMIC | 0. 1uF | | 50V |
| C453 | 1-126-963-11 | ELECT | 4. 7uF | 20% | 50V |
| C454 | 1-104-664-11 | ELECT | 47uF | 20% | 16V |
| C455 | 1-102-963-00 | CERAMIC | 33PF | 5% | 50V |
| C456 | 1-126-963-11 | ELECT | 4. 7uF | 20% | 50V |
| C457 | 1-130-481-00 | MYLAR | 0. 0068uF | 5% | 50V |
| C458 | 1-136-163-00 | FILM | 0. 068uF | 5% | 50V |
| C459 | 1-130-477-00 | MYLAR | 0. 0033uF | 5% | 50V |
| C460 | 1-136-159-00 | FILM | 0. 033uF | 5% | 50V |
| C803 | 1-164-159-11 | CERAMIC | 0. 1uF | | 50V |
| C804 | 1-124-916-11 | ELECT | 22uF | 20% | 63V |
| C805 | 1-162-294-31 | CERAMIC | 0. 001uF | 10% | 50V |
| C806 | 1-164-159-11 | CERAMIC | 0. 1uF | | 50V |
| C807 | 1-124-465-00 | ELECT | 0. 47uF | 20% | 50V |
| C808 | 1-104-905-11 | CAP, DOUBLE LAYERS | | 0. 22F | |
| C811 | 1-126-963-11 | ELECT | 4. 7uF | 20% | 50V |
| C911 | 1-124-907-11 | ELECT | 10uF | 20% | 50V |
| | | < CONNECTOR > | | | |
| CNFA81 | 1-764-922-11 | CONNECTOR, FFC (LIF(NON-ZIF)) | 17P | | |
| CNFA82 | 1-764-920-11 | CONNECTOR, FFC (LIF(NON-ZIF)) | 15P | | |
| * CNS34 | 1-561-652-00 | SOCKET, CONNECTOR | 12P | | |
| | | < DIODE > | | | |
| D801 | 8-719-914-11 | DIODE | HZ4ALL | | |
| D802-809 | | | | | |
| | 8-719-987-63 | DIODE | 1N4148M | | |
| D812 | 8-719-987-63 | DIODE | 1N4148M | | |
| D813 | 8-719-987-63 | DIODE | 1N4148M | | |
| D814 | 8-719-313-48 | LED | SEL6210S-TH12 (STSNDBY) | | |
| D911 | 8-719-000-54 | DIODE | UZL-6L3 | | |
| | | < INDICATOR TUBE > | | | |
| FL801 | 1-517-440-11 | INDICATOR TUBE, FLUORESCENT | | | |

PANEL PS

| Ref. No. | Part No. | Description | Remark |
|----------------|--------------|---------------------|--------|
| < IC > | | | |
| IC402 | 8-759-634-51 | IC M5218AP | |
| IC801 | 8-759-343-05 | IC uPD75212-SOX2168 | |
| IC802 | 8-749-923-11 | IC GPIU58XB | |
| < TRANSISTOR > | | | |
| Q801 | 8-729-900-63 | TRANSISTOR DTA124ES | |
| Q802 | 8-729-900-36 | TRANSISTOR DTC124ES | |
| Q805 | 8-729-900-63 | TRANSISTOR DTA124ES | |
| Q806 | 8-729-900-63 | TRANSISTOR DTA124ES | |
| Q807 | 8-729-900-36 | TRANSISTOR DTC124ES | |
| Q808 | 8-729-900-36 | TRANSISTOR DTC124ES | |
| < RESISTOR > | | | |
| R401 | 1-247-887-00 | CARBON 220K 5% 1/4W | |
| R402 | 1-249-430-11 | CARBON 12K 5% 1/4W | |
| R403 | 1-247-887-00 | CARBON 220K 5% 1/4W | |
| R404 | 1-249-434-11 | CARBON 27K 5% 1/4W | |
| R405 | 1-249-422-11 | CARBON 2.7K 5% 1/4W | |
| R407 | 1-249-426-11 | CARBON 5.6K 5% 1/4W | |
| R408 | 1-249-414-11 | CARBON 560 5% 1/4W | |
| R451 | 1-247-887-00 | CARBON 220K 5% 1/4W | |
| R452 | 1-249-430-11 | CARBON 12K 5% 1/4W | |
| R453 | 1-247-887-00 | CARBON 220K 5% 1/4W | |
| R454 | 1-249-434-11 | CARBON 27K 5% 1/4W | |
| R455 | 1-249-422-11 | CARBON 2.7K 5% 1/4W | |
| R457 | 1-249-426-11 | CARBON 5.6K 5% 1/4W | |
| R458 | 1-249-414-11 | CARBON 560 5% 1/4W | |
| R803-808 | 1-249-433-11 | CARBON 22K 5% 1/4W | |
| R809 | 1-249-425-11 | CARBON 4.7K 5% 1/4W | |
| R811 | 1-249-433-11 | CARBON 22K 5% 1/4W | |
| R812 | 1-249-433-11 | CARBON 22K 5% 1/4W | |
| R814 | 1-249-425-11 | CARBON 4.7K 5% 1/4W | |
| R815-818 | 1-249-433-11 | CARBON 22K 5% 1/4W | |
| R820 | 1-249-433-11 | CARBON 22K 5% 1/4W | |
| R822 | 1-249-433-11 | CARBON 22K 5% 1/4W | |
| R823 | 1-249-441-11 | CARBON 100K 5% 1/4W | |
| R824-826 | 1-249-433-11 | CARBON 22K 5% 1/4W | |
| R827 | 1-249-429-11 | CARBON 10K 5% 1/4W | |
| R828 | 1-249-433-11 | CARBON 22K 5% 1/4W | |
| R829 | 1-249-431-11 | CARBON 15K 5% 1/4W | |
| R830 | 1-249-411-11 | CARBON 330 5% 1/4W | |
| R831 | 1-249-429-11 | CARBON 10K 5% 1/4W | |
| R833 | 1-249-413-11 | CARBON 470 5% 1/4W | |
| R834 | 1-247-807-31 | CARBON 100 5% 1/4W | |

| Ref. No. | Part No. | Description | Remark |
|-----------------------------------|--------------|--------------------------------------|--------|
| R835-846 | 1-249-441-11 | CARBON 100K 5% 1/4W | |
| R847-849 | 1-249-425-11 | CARBON 4.7K 5% 1/4W | |
| R851 | 1-249-433-11 | CARBON 22K 5% 1/4W | |
| R852 | 1-249-433-11 | CARBON 22K 5% 1/4W | |
| < VARIABLE RESISTOR > | | | |
| RV402 | 1-238-157-11 | RES, VAR, CARBON 100K/100K (BASS) | |
| RV403 | 1-238-157-11 | RES, VAR, CARBON 100K/100K (TREBLE) | |
| RV404 | 1-238-156-11 | RES, VAR, CARBON 250K/250K (BALANCE) | |
| < SWITCH > | | | |
| S802 | 1-554-303-21 | SWITCH, TACTILE (VIDEO SELECTOR) | |
| S803 | 1-554-303-21 | SWITCH, TACTILE (AUDIO SELECTOR) | |
| S804 | 1-554-303-21 | SWITCH, TACTILE (SURROUND MODE) | |
| S805 | 1-554-303-21 | SWITCH, TACTILE (CENTER MODE) | |
| S806 | 1-554-303-21 | SWITCH, TACTILE (MIX) | |
| S807 | 1-554-303-21 | SWITCH, TACTILE (STEREO/MONO) | |
| < VIBRATOR > | | | |
| X801 | 1-567-775-11 | VIBRATOR, CERAMIC (4.19MHz) | |
| ***** | | | |
| * A-4378-449-A PS BOARD, COMPLETE | | | |
| ***** | | | |
| < CAPACITOR > | | | |
| C012 | 1-136-163-00 | FILM 0.068uF 5% 50V | |
| C013 | 1-136-163-00 | FILM 0.068uF 5% 50V | |
| C512 | 1-136-163-00 | FILM 0.068uF 5% 50V | |
| C513 | 1-136-163-00 | FILM 0.068uF 5% 50V | |
| C562 | 1-136-163-00 | FILM 0.068uF 5% 50V | |
| C563 | 1-136-163-00 | FILM 0.068uF 5% 50V | |
| C921 | 1-106-220-00 | MYLAR 0.1uF 5% 100V | |
| C922 | 1-111-263-11 | ELECT 10000uF 20% 56V | |
| C923 | 1-111-263-11 | ELECT 10000uF 20% 56V | |
| C924 | 1-124-910-11 | ELECT 47uF 20% 50V | |
| C925 | 1-124-910-11 | ELECT 47uF 20% 50V | |
| C926 | 1-106-220-00 | MYLAR 0.1uF 5% 100V | |
| C927 | 1-126-413-11 | ELECT 3300uF 20% 35V | |
| C928 | 1-126-413-11 | ELECT 3300uF 20% 35V | |
| C933 | 1-126-941-11 | ELECT 470uF 20% 16V | |
| C971 | 1-106-220-00 | MYLAR 0.1uF 5% 100V | |
| C972 | 1-124-920-11 | ELECT 330uF 20% 63V | |
| C973 | 1-124-920-11 | ELECT 330uF 20% 63V | |
| C976 | 1-106-220-00 | MYLAR 0.1uF 5% 100V | |

PS

PW. SW

SP. SW

| Ref.No. | Part No. | Description | Remark |
|---------------|--------------|------------------------------|--------|
| < CONNECTOR > | | | |
| * CNP11 | 1-691-670-11 | CONNECTOR, BOARD TO BOARD 5P | |
| * CNP51-54 | 1-564-976-11 | PIN, CONNECTOR 6P | |
| CNP55 | 1-770-880-11 | PIN, CONNECTOR 10P | |
| CNP71 | 1-695-087-11 | PIN, CONNECTOR (PC BOARD) 7P | |
| CNP72 | 1-695-087-11 | PIN, CONNECTOR (PC BOARD) 7P | |
| CNP73 | 1-750-180-11 | PIN, CONNECTOR (PC BOARD) 5P | |
| CNP940 | 1-750-180-11 | PIN, CONNECTOR (PC BOARD) 5P | |
| * CNV923 | 1-564-104-00 | PIN, CONNECTOR (B3P-VH) 3P | |
| * CNV924 | 1-564-242-00 | PIN, CONNECTOR 5P | |

< DIODE >

| | | | |
|------|--------------|-------|------------|
| D712 | 8-719-987-63 | DIODE | 1N4148M |
| D717 | 8-719-987-63 | DIODE | 1N4148M |
| D722 | 8-719-987-63 | DIODE | 1N4148M |
| D727 | 8-719-987-63 | DIODE | 1N4148M |
| D920 | 8-719-302-38 | DIODE | RBV-602-01 |
| D921 | 8-719-200-82 | DIODE | 11ES2 |
| D922 | 8-719-934-15 | DIODE | HZS24-3L |
| D923 | 8-719-200-02 | DIODE | 10E2 |
| D924 | 8-719-200-02 | DIODE | 10E2 |
| D925 | 8-719-025-03 | DIODE | RBA-402-SL |
| D927 | 8-719-200-82 | DIODE | 11ES2 |
| D929 | 8-719-200-82 | DIODE | 11ES2 |

< TERMINAL BOARD >

| | | | |
|-----|--------------|------------------------|--|
| E91 | 1-537-770-21 | TERMINAL BOARD, GROUND | |
| E92 | 1-537-770-21 | TERMINAL BOARD, GROUND | |

< COIL >

| | | | |
|--------|--------------|----------------|--|
| * L001 | 1-420-872-00 | COIL, AIR-CORE | |
| * L501 | 1-420-872-00 | COIL, AIR-CORE | |
| * L551 | 1-420-872-00 | COIL, AIR-CORE | |

< TRANSISTOR >

| | | | |
|------|--------------|------------|-----------|
| Q921 | 8-729-141-03 | TRANSISTOR | 2SA733-QP |
|------|--------------|------------|-----------|

< RESISTOR >

| | | | | | |
|------|--------------|--------|------|----|------|
| R030 | 1-247-727-11 | CARBON | 10 | 5% | 1/2W |
| R031 | 1-247-727-11 | CARBON | 10 | 5% | 1/2W |
| R033 | 1-249-437-11 | CARBON | 47K | 5% | 1/4W |
| R034 | 1-249-421-11 | CARBON | 2.2K | 5% | 1/4W |
| R035 | 1-249-433-11 | CARBON | 22K | 5% | 1/4W |
| R036 | 1-249-409-11 | CARBON | 220 | 5% | 1/4W |
| R037 | 1-249-421-11 | CARBON | 2.2K | 5% | 1/4W |
| R530 | 1-247-727-11 | CARBON | 10 | 5% | 1/2W |
| R531 | 1-247-727-11 | CARBON | 10 | 5% | 1/2W |

| Ref.No. | Part No. | Description | Remark |
|---------|--------------|-------------|---------------|
| R532 | 1-247-749-11 | CARBON | 560 5% 1/2W |
| R533 | 1-249-437-11 | CARBON | 47K 5% 1/4W |
| R535 | 1-249-433-11 | CARBON | 22K 5% 1/4W |
| R536 | 1-249-419-11 | CARBON | 1.5K 5% 1/4W |
| R538 | 1-249-431-11 | CARBON | 15K 5% 1/4W |
| R580 | 1-247-727-11 | CARBON | 10 5% 1/2W |
| R581 | 1-247-727-11 | CARBON | 10 5% 1/2W |
| R582 | 1-247-749-11 | CARBON | 560 5% 1/2W |
| R583 | 1-249-437-11 | CARBON | 47K 5% 1/4W |
| R584 | 1-249-431-11 | CARBON | 15K 5% 1/4W |
| R585 | 1-249-433-11 | CARBON | 22K 5% 1/4W |
| R586 | 1-249-419-11 | CARBON | 1.5K 5% 1/4W |
| R611 | 1-249-437-11 | CARBON | 47K 5% 1/4W |
| R661 | 1-249-437-11 | CARBON | 47K 5% 1/4W |
| R704 | 1-249-417-11 | CARBON | 1K 5% 1/4W |
| R713 | 1-247-743-11 | CARBON | 220 5% 1/2W |
| R723 | 1-247-743-11 | CARBON | 220 5% 1/2W |
| R922 | 1-249-425-11 | CARBON | 4.7K 5% 1/4W |
| △R925 | 1-247-688-11 | CARBON | 10 5% 1/4W F |
| △R928 | 1-249-455-11 | CARBON | 4.7 5% 1/4W F |
| △R975 | 1-247-688-11 | CARBON | 10 5% 1/4W F |

< RELAY >

| | | | |
|-------|--------------|-------------|--|
| RY001 | 1-515-920-11 | RELAY (24V) | |
| RY501 | 1-515-920-11 | RELAY (24V) | |
| RY502 | 1-515-614-11 | RELAY | |
| RY601 | 1-515-920-11 | RELAY (24V) | |

| | | |
|----------------|-------------|-------|
| * 1-657-058-11 | PW.SW BOARD | ***** |
|----------------|-------------|-------|

< CONNECTOR >

| | | | |
|---------|--------------|-------------------|--|
| * CND89 | 1-564-336-00 | PIN, CONNECTOR 2P | |
|---------|--------------|-------------------|--|

< SWITCH >

| | | | |
|-------|--------------|---|--|
| △S901 | 1-572-267-51 | SWITCH, PUSH (AC POWER) (1 KEY) (POWER) | |
|-------|--------------|---|--|

| | | |
|----------------|-------------|-------|
| * 1-657-055-11 | SP.SW BOARD | ***** |
|----------------|-------------|-------|

< CONNECTOR >

| | | | |
|-------|--------------|--------------------|--|
| CNE81 | 1-564-505-11 | PLUG, CONNECTOR 2P | |
|-------|--------------|--------------------|--|

< SWITCH >

| | | | |
|------|--------------|--------------------------------|--|
| S851 | 1-572-709-11 | SWITCH, PUSH (1 KEY) (SPEAKER) | |
|------|--------------|--------------------------------|--|

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

| | | | |
|-----|-----|----|-------|
| SPC | SPF | VF | VIDEO |
|-----|-----|----|-------|

| Ref.No. | Part No. | Description | Remark |
|----------|--------------|--|--------|
| * | 1-657-067-11 | SPC BOARD ***** < CONNECTOR > | |
| CNP56 | 1-770-481-11 | PIN, CONNECTOR 4P | |
| * CNS55 | 1-561-205-11 | SOCKET 10P < TERMINAL > | |
| TM001 | 1-536-707-21 | TERMINAL BOARD, PUSH 2P (CENTER SPEAKER) | |
| TM601 | 1-537-238-11 | TERMINAL BOARD (REAR SPEAKER) | |
| ***** | | | |
| * | 1-657-068-11 | SPF BOARD ***** < CONNECTOR > | |
| CNS56 | 1-770-569-11 | SOCKET 4P < TERMINAL > | |
| TM501 | 1-537-238-11 | TERMINAL BOARD (FRONT SPEAKER) | |
| ***** | | | |
| * | 1-657-054-11 | VF BOARD ***** < CAPACITOR > | |
| C209 | 1-164-159-11 | CERAMIC 0.1uF 50V < CONNECTOR > | |
| CNE24 | 1-691-767-41 | PLUG (MICRO CONNECTOR) 5P | |
| * CNE29 | 1-564-506-11 | PLUG, CONNECTOR 3P < JACK > | |
| J151 | 1-537-115-31 | TERMINAL BOARD (VIDEO 4 INPUT) < RESISTOR > | |
| R123 | 1-249-417-11 | CARBON 1K 5% 1/4W | |
| R173 | 1-249-417-11 | CARBON 1K 5% 1/4W | |
| R221 | 1-249-403-11 | CARBON 68 5% 1/4W | |
| R283 | 1-249-403-11 | CARBON 68 5% 1/4W | |
| R284 | 1-249-403-11 | CARBON 68 5% 1/4W | |
| ***** | | | |
| * | A-4378-428-A | VIDEO BOARD, COMPLETE ***** < CAPACITOR > | |
| C201-204 | 1-124-903-11 | ELECT 1uF 20% 50V | |

| Ref.No. | Part No. | Description | Remark |
|---------------|--------------|--|--------|
| C205-207 | | | |
| | 1-124-907-11 | ELECT 10uF 20% 50V | |
| C208 | 1-124-903-11 | ELECT 1uF 20% 50V | |
| C210 | 1-104-664-11 | ELECT 47uF 20% 16V | |
| C211 | 1-104-664-11 | ELECT 47uF 20% 16V | |
| C251 | 1-124-907-11 | ELECT 10uF 20% 50V | |
| C252 | | | |
| | 1-136-153-00 | FILM 0.01uF 5% 50V | |
| C253 | 1-124-903-11 | ELECT 1uF 20% 50V | |
| C254 | 1-136-165-00 | FILM 0.1uF 5% 50V | |
| C255 | 1-124-907-11 | ELECT 10uF 20% 50V | |
| C256 | 1-136-153-00 | FILM 0.01uF 5% 50V | |
| C257 | | | |
| | 1-124-903-11 | ELECT 1uF 20% 50V | |
| C258 | 1-136-165-00 | FILM 0.1uF 5% 50V | |
| C259 | 1-124-903-11 | ELECT 1uF 20% 50V | |
| C260 | 1-136-165-00 | FILM 0.1uF 5% 50V | |
| C291-293 | | | |
| | 1-164-159-11 | CERAMIC 0.1uF 50V | |
| < CONNECTOR > | | | |
| CNE22 | 1-691-767-41 | PLUG (MICRO CONNECTOR) 5P | |
| CNP21 | 1-695-089-11 | PIN, CONNECTOR (PC BOARD) 11P < DIODE > | |
| D290 | | | |
| | 8-719-987-63 | DIODE 1N4148M < IC > | |
| IC201 | | | |
| | 8-759-061-95 | IC SN761200 | |
| IC251 | 8-759-061-95 | IC SN761200 | |
| IC252 | 8-759-061-95 | IC SN761200 < JACK > | |
| J201 | 1-565-351-61 | JACK, PIN 3P (LD/VIDEO 3/VIDEO 2 OUT) | |
| J202 | 1-565-319-11 | JACK, PIN 2P (VIDEO 2 IN/VIDEO 1 OUT) | |
| J203 | 1-565-319-11 | JACK, PIN 2P (VIDEO 1 IN/MONITOR) | |
| J251 | 1-764-676-11 | CONNECTOR (ROUND TYPE) (LD S VIDEO IN/VIDEO 1 S VIDEO OUT) | |
| J252 | 1-764-676-11 | CONNECTOR (ROUND TYPE) (VIDEO 1 S VIDEO IN/MONITOR S VIDEO OUT) | |
| J290 | | | |
| | 1-566-740-11 | JACK (CONTROL S) < COIL > | |
| L201 | | | |
| | 1-410-521-11 | INDUCTOR 100uH | |
| L202 | 1-410-521-11 | INDUCTOR 100uH < TRANSISTOR > | |
| Q201 | 8-729-620-05 | TRANSISTOR 2SC2603-BF | |
| Q202 | 8-729-119-76 | TRANSISTOR 2SA1175-HFE | |
| Q203 | 8-729-620-05 | TRANSISTOR 2SC2603-BF | |

VIDEO

VOL

VS

| Ref. No. | Part No. | Description | Remark |
|--------------|--------------|-------------|--------------|
| Q204 | 8-729-119-76 | TRANSISTOR | 2SA1175-HFE |
| Q205 | 8-729-620-05 | TRANSISTOR | 2SC2603-EF |
| Q206 | 8-729-119-76 | TRANSISTOR | 2SA1175-HFE |
| Q207 | 8-729-900-89 | TRANSISTOR | DTC144ES |
| Q251 | 8-729-620-05 | TRANSISTOR | 2SC2603-EF |
| Q252 | 8-729-119-76 | TRANSISTOR | 2SA1175-HFE |
| Q253 | 8-729-119-76 | TRANSISTOR | 2SA1175-HFE |
| Q254 | 8-729-620-05 | TRANSISTOR | 2SC2603-EF |
| Q255 | 8-729-119-76 | TRANSISTOR | 2SA1175-HFE |
| Q256 | 8-729-119-76 | TRANSISTOR | 2SA1175-HFE |
| Q290 | 8-729-900-80 | TRANSISTOR | DTC114ES |
| Q291 | 8-729-900-61 | TRANSISTOR | DTA114ES |
| < RESISTOR > | | | |
| R201-206 | | | |
| | 1-249-403-11 | CARBON | 68 5% 1/4W |
| R207 | 1-249-426-11 | CARBON | 5.6K 5% 1/4W |
| R208 | 1-249-419-11 | CARBON | 1.5K 5% 1/4W |
| R209 | 1-249-430-11 | CARBON | 12K 5% 1/4W |
| R210 | 1-249-403-11 | CARBON | 68 5% 1/4W |
| R211 | 1-249-403-11 | CARBON | 68 5% 1/4W |
| R212 | 1-249-426-11 | CARBON | 5.6K 5% 1/4W |
| R213 | 1-249-419-11 | CARBON | 1.5K 5% 1/4W |
| R214 | 1-249-430-11 | CARBON | 12K 5% 1/4W |
| R215 | 1-249-403-11 | CARBON | 68 5% 1/4W |
| R216 | 1-249-403-11 | CARBON | 68 5% 1/4W |
| R217 | 1-249-426-11 | CARBON | 5.6K 5% 1/4W |
| R218 | 1-249-419-11 | CARBON | 1.5K 5% 1/4W |
| R219 | 1-249-430-11 | CARBON | 12K 5% 1/4W |
| R220 | 1-249-409-11 | CARBON | 220 5% 1/4W |
| R252 | 1-249-403-11 | CARBON | 68 5% 1/4W |
| R254 | 1-249-429-11 | CARBON | 10K 5% 1/4W |
| R255 | 1-249-403-11 | CARBON | 68 5% 1/4W |
| R256 | 1-249-403-11 | CARBON | 68 5% 1/4W |
| R257 | 1-249-426-11 | CARBON | 5.6K 5% 1/4W |
| R258 | 1-249-419-11 | CARBON | 1.5K 5% 1/4W |
| R259 | 1-249-430-11 | CARBON | 12K 5% 1/4W |
| R260 | 1-249-413-11 | CARBON | 470 5% 1/4W |
| R261 | 1-247-807-31 | CARBON | 100 5% 1/4W |
| R264-267 | | | |
| | 1-249-403-11 | CARBON | 68 5% 1/4W |
| R268 | 1-249-426-11 | CARBON | 5.6K 5% 1/4W |
| R269 | 1-249-419-11 | CARBON | 1.5K 5% 1/4W |
| R270 | 1-249-430-11 | CARBON | 12K 5% 1/4W |
| R271 | 1-249-403-11 | CARBON | 68 5% 1/4W |
| R272 | 1-249-429-11 | CARBON | 10K 5% 1/4W |
| R273 | 1-249-413-11 | CARBON | 470 5% 1/4W |
| R274 | 1-247-807-31 | CARBON | 100 5% 1/4W |
| R275 | 1-249-403-11 | CARBON | 68 5% 1/4W |

| Ref. No. | Part No. | Description | Remark |
|------------------------|--------------|---|---------------|
| R276 | 1-249-403-11 | CARBON | 68 5% 1/4W |
| R290 | 1-249-421-11 | CARBON | 2.2K 5% 1/4W |
| ***** | | | |
| * | 1-657-052-11 | VOL BOARD | ***** |
| < CAPACITOR > | | | |
| C348 | 1-126-963-11 | ELECT | 4.7uF 20% 50V |
| C638 | 1-136-153-00 | FILM | 0.01uF 5% 50V |
| < CONNECTOR > | | | |
| CNE33 | 1-691-771-11 | PLUG (MICRO CONNECTOR) 9P | |
| CNE61 | 1-564-505-11 | PLUG, CONNECTOR 2P | |
| * CNP34 | 1-560-443-11 | PIN, CONNECTOR 12P | |
| CNS32 | 1-695-093-11 | SOCKET, CONNECTOR 9P | |
| < TERMINAL BOARD > | | | |
| E61 | 1-537-770-21 | TERMINAL BOARD, GROUND | |
| < IC > | | | |
| IC306 | 8-759-634-51 | IC M5218AP | |
| IC654 | 8-759-820-62 | IC LB1639 | |
| < RESISTOR > | | | |
| R341 | 1-249-429-11 | CARBON | 10K 5% 1/4W |
| R342 | 1-249-431-11 | CARBON | 15K 5% 1/4W |
| R344 | 1-249-425-11 | CARBON | 4.7K 5% 1/4W |
| R345 | 1-249-429-11 | CARBON | 10K 5% 1/4W |
| R649 | 1-249-413-11 | CARBON | 470 5% 1/4W |
| < VARIABLE RESISTOR > | | | |
| RV401 | 1-241-563-11 | RES, VAR, CARBON 100KX4 (MASTER VOLUME) | |
| ***** | | | |
| * | 1-657-057-11 | VS BOARD (E) | ***** |
| < CONNECTOR > | | | |
| * CNV913 | 1-564-321-21 | PIN, CONNECTOR 2P (E) | |
| CNV914 | 1-564-321-00 | PIN, CONNECTOR 2P (E) | |
| CNV915 | 1-568-106-11 | PIN, CONNECTOR 4P (E) | |
| < SWITCH > | | | |
| △S9 | 1-571-437-11 | SWITCH, POWER VOLTAGE CHANGE | |
| (VOLTAGE SELECTOR) (E) | | | |
| ***** | | | |

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

| Ref. No. | Part No. | Description | Remark |
|----------|--------------|---|--------|
| | | MISCELLANEOUS ***** | |
| 13 | 1-773-644-11 | WIRE (FLAT TYPE) (17 CORE) | |
| 14 | 1-773-623-11 | WIRE (FLAT TYPE) (15 CORE) | |
| * 51 | 1-533-213-31 | HOLDER, FUSE | |
| △CNJ902 | 1-526-794-11 | OUTLET, AC (AEP, G, SP, CH) | |
| △CNP1 | 1-558-943-41 | CORD, POWER (E) | |
| △CNP1 | 1-575-651-21 | CORD, POWER (AEP, G, SP, CH) | |
| △CNP1 | 1-696-586-11 | CORD, POWER (UK) | |
| △F1 | 1-532-286-00 | FUSE (T2. 5AL/250V) | |
| △F2 | 1-532-286-00 | FUSE (T2. 5AL/250V) (AEP, G, SP, CH) | |
| △F3 | 1-532-286-00 | FUSE (T2. 5AL/250V) (E) | |
| △F901 | 1-532-299-00 | FUSE (T5AL/250V) | |
| △F902 | 1-532-299-00 | FUSE (T5AL/250V) | |
| △T1 | 1-427-982-11 | TRANSFORMER, POWER (AEP, UK, G, SP, CH) | |
| △T1 | 1-427-983-11 | TRANSFORMER, POWER (E) | |
| ***** | | | |
| | | ACCESSORIES & PACKING MATERIALS ***** | |
| | 1-473-199-11 | COMMANDER, STANDARD (RM-P590) | |
| | 3-681-190-01 | SHEET (LARGE), PROTECTION | |
| | 3-798-902-11 | MANUAL, INSTRUCTION (ENGLISH/FRENCH/ SPANISH/PORTUGUESE) (AEP, UK) | |
| | 3-798-902-21 | MANUAL, INSTRUCTION (GERMAN/DUTCH/ DUTCH/SWEDISH/ITALIAN) (AEP, G) | |
| | 3-798-902-31 | MANUAL, INSTRUCTION (ENGLISH/FRENCH/ SPANISH/CHINESE) (E, SP, CH) | |
| | 3-798-902-41 | MANUAL, INSTRUCTION (DANISH/FINNISH) (AEP) | |
| | 4-925-079-11 | COVER (6), BATTERY (FOR RM-P590) | |
| | 4-933-001-01 | CUSHION | |
| | 4-976-234-01 | INDIVIDUAL CARTON | |
| ***** | | | |
| | | ***** HARDWARE LIST ***** | |
| #1 | 7-685-646-79 | SCREW +BVTP 3×8 TYPE2 IT-3 | |
| #2 | 7-685-646-81 | SCREW +BVTP 3×8 TYPE2 | |
| #3 | 7-685-647-79 | SCREW +BVTP 3×10 TYPE2 IT-3 | |
| #4 | 7-682-560-04 | SCREW +BVTT 4×6 (S) | |

The components identified by
mark △ or dotted line with mark
△ are critical for safety.
Replace only with part number
specified.

Sony Corporation
Consumer A&V Products Company
Home A&V Products Div.

9-960-244-11

English
95E0281-1
Printed in Japan
© 1995.5
Published by Home A&V Products Div.
Quality Engineering Dept.